

1

Modular Communication

2

Interface Specification for Demand Response

4

5 Revision History

Version 1.1	Original	Contribution to the H2G DEWG from the EPRI / USNAP Merging Project
<u>Version 1.2</u>		<u>Incorporation of responses to round 1 H2G DEWG Comments</u>
<u>Version 1.3</u>		<u>Adjustments after 7/29 meeting of the comments resolutions team</u>

6

8 Contents

9	1	<u>Introduction</u>	4
10	1.1	<u>Acronyms & Abbreviations</u>	4
11	2	<u>Physical/Electrical Interface</u>	5
12	3	<u>Serial Protocol</u>	5
13	3.1.1	<u>Message Type Field</u>	6
14	3.1.2	<u>Payload Length Field</u>	7
15	3.1.3	<u>Checksum Field</u>	7
16	3.1.4	<u>Bit and Byte Order</u>	7
17	3.1.5	<u>Message Synchronization and Timing</u>	7
18	3.1.6	<u>Randomized Data-Link Retries</u>	8
19	3.1.7	<u>SGD Handling of Conflicting Messages</u>	98
20	4	<u>Simple Implementation</u>	9
21	5	<u>Data Link Messages</u>	9
22	5.1.1	<u>Link NAK Error Codes</u>	<u>1512</u>
23	5.1.2	<u>Interface Power Limit Negotiation</u>	<u>1613</u>
24	5.1.3	<u>Bit Rate Negotiation</u>	<u>1714</u>
25	5.1.4	<u>Message Type support Query</u>	<u>1814</u>
26	5.1.5	<u>Power-Up and State Reset</u>	<u>1815</u>
27	6	<u>“Basic DR” Application (Message Type = 0x08, 0x01)</u>	<u>1815</u>
28	6.1.1	<u>Basic Message Fixed Length</u>	<u>2419</u>
29	6.1.2	<u>Event Duration Field</u>	<u>2419</u>
30	6.1.3	<u>Grouped Messages</u>	<u>2520</u>
31	6.2	<u>Usage and Details of Basic DR Application Messages</u>	<u>2520</u>
32	6.2.1	<u>Request for Power Level (Opcode 0x06)</u>	<u>2520</u>
33	6.2.2	<u>Relative Price Commands (Opcode 0x07 and 0x08)</u>	<u>2621</u>
34	6.2.3	<u>Time Remaining in Present Price Period (Opcode 0x09)</u>	<u>2722</u>
35	6.2.4	<u>Operating State Monitoring (Opcodes 0x12 and 0x13)</u>	<u>2822</u>
36	7	<u>Intermediate DR Application (Message Type = 0x08, 0x02)</u>	<u>2923</u>
37	7.1	<u>Usage and Details of Intermediate DR Application Messages</u>	<u>3226</u>
38	7.1.1	<u>Info Request</u>	<u>3226</u>
39	7.1.2	<u>Get/Set UTC Time</u>	<u>3528</u>
40	7.1.3	<u>Get/Set Energy Price</u>	<u>3629</u>
41	7.1.4	<u>Get/Set Tier</u>	<u>3731</u>
42	7.1.5	<u>Get/Set Temperature Offset</u>	<u>3832</u>
43	7.1.6	<u>Get/Set Set Point</u>	<u>3932</u>
44	7.1.7	<u>Automomous Cycling</u>	<u>4034</u>
45	7.1.8	<u>Demand Reduction – Terminate Cycling</u>	<u>4135</u>

46	7.2 Demand Response Event Schedules	4235
47	7.2.1 Send Scheduled Events Request	4235
48	8 Commissioning and Network Messages (Message Type = 0x08, 0x04)	4236
49	9 Pass-Through of Standard Protocols	4337
50	9.1 Example Pass-Through Handling Instructions.....	4438
51	9.1.1 USNAP 1.0 Protocol Pass-Through.....	4438
52	9.1.2 SEP1.0 Pass-Through.....	4538
53	9.1.3 ClimateTalk Pass-Through.....	4538
54	9.1.4 General Internet Protocol Pass-Through	4539
55	10 Example Communication Exchanges.....	4740
56	11 General Security Principles	4841
57	12 Load Management Event Randomization	4842
58	13 Appendix A – Low Voltage DC Form Factor	5043
59	13.1 Overview	5043
60	13.1.1 Limitations.....	5043
61	13.2 Physical Layer.....	5043
62	13.2.1 Power for UCM.....	5043
63	13.2.2 Mechanical Interface	5043
64	13.3 Data Link.....	5951
65	13.3.1 Messages.....	6051
66	13.3.2 Operation	6253
67	14 Appendix B – AC Form Factor	6556
68	14.1.1 Physical Form	6656
69	14.1.2 AC Power.....	6657
70	14.1.3 Serial Electrical Interface.....	6657
71	14.1.4 Obtaining Message Sync	6758
72	15 Appendix C – Fletcher Checksum	6960
73	15.1 Calculating the Checksum	6960
74	15.2 Decoding the Checksum.....	6960
75	15.3 Example VB Code	6960
76	16 Appendix D – Guideline for Computing Average Price.....	7061
77	Explanation for non-regulated utilities.....	7162
78	Summary	7363
79		

81 1 Introduction

82 This document is a specification for a modular communication interface. The specification details the
 83 mechanical, electrical, and logical characteristics of a socket interface that allows communication
 84 devices (hereafter referred-to as UCMs – universal communication modules) to be separated from end
 85 devices (hereafter referred-to as SGDs – Smart Grid Devices). Although the potential applications of this
 86 technology are wide-ranging, it is intended at a minimum to provide a means by which residential
 87 products may be able to work with any load management system through user installable plug-in
 88 communication modules. Figure 1.1 illustrates the general concept.



90 **Figure 1.1 – Illustrations of the Modular Communication Concept on an Appliance (left) or Energy
 91 Management Console (right)**

92 This specification identifies the physical and data link characteristics of the interface, along with certain
 93 network and application layer elements as needed to assure interoperability over a broad range of
 94 device capabilities. In addition, it defines a mechanism through which application layer messages
 95 (defined in other standards) may be passed across the interface.

96 The scope of this specification is limited to the socket interface between the UCM and the SGD. It does
 97 not address the technology or protocol associated with the communication system of which the UCM is
 98 part.

99 1.1 Acronyms & Abbreviations

SGD	Smart Grid Device – the end device that is being informed of grid conditions
UCM	Universal Communication Module – the communications device that provides communication connectivity to an SGD
SPI	Serial Peripheral Interface – data transfer standard originally defined by

	Motorola (Freescale)
0x00 – 0xFF	Two digit (8 bit) hexadecimal numbers ranging from 0 to 255 decimal
b0, b1 .. b15	Bit values within a hexadecimal number. b0 is lsb.
MS	Abbreviation for Most Significant
LS	Abbreviation for Least Significant

100 **2 Physical/Electrical Interface**

101 Two physical form factors are presently defined. End device manufacturers may choose either, and
 102 communication module providers who wish to cover all products may offer two module versions. For
 103 both form factors, the communication protocol across the socket interface is the same, as described
 104 herein. Also in both cases, the power for the UCM is provided by the SGD. One form factor provides a
 105 low-voltage DC supply and an SPI serial data interface. This form factor is described in detail in
 106 **Appendix A** of this document. This option might be attractive in cases where the end device has no AC
 107 power source or when smaller socket size is required.

108 The second form factor provides AC service voltage (120/240V) and an RS-485 based serial interface.
 109 This form factor is described in detail in **Appendix B** of this document. This option might be attractive in
 110 cases where the end device does not provide a DC power supply, where compatibility with PLC
 111 communication modules is desired, or where communication module access to line frequency is
 112 needed.



113

114

Figure 2.1 – PLC Communication Module Example

115 **3 Serial Protocol**

116 This specification defines an extensible serial protocol data unit that is manageable by the simplest of
 117 devices and also capable of being extended to accommodate the more complex. The general message
 118 format is as follows:

Message Type	Payload Length	Payload	Checksum
2 Bytes	2 Bytes	Variable	2 Bytes

119

Table 3-1–Protocol Data Unit Format

120 The idea in this design is that the “payload” part of the message can transport a range of protocols, with
 121 the “Message Type” field indicating what protocol and the checksum included so as to assure link-layer
 122 data integrity. This scheme provides a high level of flexibility and extensibility. A simple means is
 123 provided for SGDs and UCMs to discover which protocols one another support

124 **3.1.1 Message Type Field**

125 The “Message Type” bytes indicate the type of message, essentially indicating which communication
 126 protocol is represented in the payload. The following “Message Type” values are specified:

Message Type MS Byte	Message Type LS Byte	Description
0x00 to 0x05	0x00 to 0xFF	Reserved for vendor proprietary use
0x06	0x00 to 0xFF	Reserved to avoid confusion with link layer ACK
0x07	0x00 to 0xFF	For Future Assignment
0x08	0x01	Basic DR Application (at least partially supported by all devices)
0x08	0x02	Intermediate DR Application
0x08	0x03	Data Link Messages
0x08	0x04	Commissioning and Network Support Messages
0x08	0x05 to 0xFF	For Future Assignment
0x09	0x01	USNAP 1.0, Pass-Through
0x09	0x02	ClimateTalk, Pass-Through
0x09	0x03	Smart Energy Profile 1.0, Pass-Through
0x09	0x04	Smart Energy Profile 2.0 over IP, Pass-Through
0x09	0x05	OpenADR1.0 over IP, Pass-Through
0x09	0x06	OpenADR2.0 over IP, Pass-Through
0x09	0x07	Generic IP Pass-Through (IP packets self-identify version so both IPV4 and IPV6 are covered)
0x09	0x08 to 0xFF	For Future Assignment
0x0A to 0x14	0x00 to 0xFF	For Future Assignment
0x15	0x00 to 0xFF	Reserved to avoid confusion with link layer NAK
0x16 to 0xEF	0x00 to 0xFF	For Future Assignment
0xF0 to 0xFF	0x00 to 0xFF	Reserved for vendor proprietary use

127

Table 3-2 – Message Type Assignments

128 The “Vendor Proprietary” message types allow for device makers to make use of the serial interface for
129 any purpose they wish. This includes manufacturing processes, field diagnostics, etc. Once a message
130 begins with an address in these vendor-proprietary ranges, the remainder of the message may be
131 formatted and used as desired by the manufacturer. In cases where the appliance has multiple internal
132 subsystems sharing the serial bus, further addressing might be handled using the second byte.

133 New Message Types are to be assigned by the standards organization that manages this interface
134 standard. Notionally, this would be done in coordination with the organization(s) responsible for the
135 management of the domain-area or protocol that is to be passed through.

136 Chapter 5 , Data-Link Messages, describes the query used to determine if a device supports a specific
137 message type. Support of the basic message type 0x08 0x01 is required and need not be queried.

138 **3.1.2 Payload Length Field**

139 The “Payload Length” is a two-byte representation of the number of bytes in the Payload field. For the
140 “Basic DR” messages, this is always a 2. Other message types may have variable payload lengths and
141 may also include additional length bytes somewhere in the message payload as defined by the other
142 protocol’s spec.

143 **3.1.3 Checksum Field**

144 The checksum is calculated starting with the first Message Type byte through to the end of the payload.
145 Checksum calculation and encoding is according to a Fletcher checksum as detailed in Appendix D.

146 **3.1.4 Bit and Byte Order**

147 All bytes are transmitted most significant bit first. Multi-byte numbers, such as the Message Type and
148 Length, are transmitted most significant byte first (Big Endian).

149 As an example, the 16 bit hexadecimal value 4143 (0x102F) would be transmitted as:


Byte	Contents	Comments
1	0x10	First byte transmitted
2	'0x2F	Last byte transmitted
2	0x2F	Last byte transmitted

150 **3.1.5 Message Synchronization and Timing**

151 All communication on this interface shall be half-duplex. This applies to both the low-voltage DC
152 interface using SPI and the high voltage AC interface using RS-485. The nature of the two-wire RS-485
153 interface fundamentally allows only one side to transmit successfully at any time.

154 The specification allows either the communication module or the end device to initiate communication.
 155 As a result, bus contention is possible on the AC interface and must be electrically tolerated by the
 156 devices on both sides without damage. Recognition of contention is to be achieved by the absence of an
 157 appropriate response and recovery by the randomized data-link retry process described in section 3.1.6
 158 .

159 Required message timing, including both link layer and application layer, are specified in [Table 3-3](#)
 160 [Table 3-3](#).



161

Parameter	Minimum	Maximum	Description
t_{MA}	40[mS]	200[mS]	Time from the end of an initial message until the beginning of an associated data-link ACK.
t_{AR}	100[mS]	3[Seconds]	Time from the end of a data-link ACK until the beginning of an application response from the same device.
t_{RA}	40[mS]	200[mS]	Time from the end of a response message until the beginning of an associated data-link ACK.
t_{IM}	100[mS]	1[Second]	Time from the end of a final data-link ACK until the beginning of a new message. The specification of 1[Second] applies only to “grouped” Basic DR messages that are intended to be processed collectively. Otherwise there is no maximum.
t_{ML}		500[mS]	Maximum message duration, from end of first byte to end of last byte.
t_{ML}		4.5[Second]	Maximum message duration, from end of first byte to end of last byte. (Accommodates 8192 bytes at 19.2KBps)

162 **Table 3-3 Message Timing Requirements**

163 **3.1.6 Randomized Data-Link Retries**

164 The data-link layer may determine failure from either lack of a response within the allowed time or from
 165 a data-link NAK with an error code indicating that the message was corrupted. Three retries are
 166 recommended at the data-link layer, with a randomized delay between each retry of 100 to 2000[mS].

167 Additional error recovery may exist at the application layer but the specific handling of such is outside
168 the scope of this specification.

169 **3.1.7 SGD Handling of Conflicting Messages**

170 This specification supports multiple possible application layer protocols, including the basic and
171 intermediate DR commands defined herein in addition to the pass-through of other industry standard
172 protocols. Among these varied protocols are many different commands related to demand response. It
173 is the responsibility of the UCM, and the system in which it participates, to provide SGDs with single,
174 clear indications of the conditions at any time. In the event that an SGD is presented with conflicting
175 commands, the last command received shall take precedence.

176 **4 Simple Implementation**

177 This specification identifies many message types and commands, but very few are mandatory. The
178 messages are grouped into several types, including a set of data-link messages, basic and intermediate
179 DR application messages, and advanced protocol pass-through messages. To be compliant with this
180 specification, UCMs and SGDs are required to support only a few messages, each of which is limited to 8
181 bytes length. Devices may optionally support additional messages as desired.

182 The mandatory messages are:

Mandatory Message	Layer	Description
Shed	Basic DR Application	Fixed, 8 byte
End Shed	Basic DR Application	Fixed, 8 byte
Application ACK/NAK	Basic DR Application	Fixed, 8 byte
Communication Good/Bad	Basic DR Application	Fixed, 8 byte
Data Link ACK/NAK	Data Link	1 (ACK) and 2(NAK) bytes

183 **Table 4-1 – Mandatory Message Summary**

184 The establishment of mandatory messages is necessary in order to guarantee that any DR
185 communication system, when connected to any end device, may still provide basic demand
186 responsiveness. The mandatory list has been minimized in recognition that many present demand
187 response systems provide only on/off control information and many end devices have only on/off
188 response capabilities.

189 **5 Data Link Messages**

190 This specification adheres to a layered technique that distinguishes the data link layer from the
191 application layer. The data link messages identified in this section are employed to manage data
192 transfer across the interface and to assure its successful delivery. Support of the data-link ACK and NAK

193 messages is mandatory, and is required in response to all messages except other data-link ACKs and
 194 NAKs (i.e. do not ACK an ACK). Use and/or support of the remaining data link commands are all
 195 optional, with a lack of support indicating that only the defaults are supported. The data-link ACK is a
 196 single byte and the data-link NAK is two bytes. The remaining data link commands follow the general
 197 protocol data unit format indicated in [Table 3-1](#)[Table 3-1](#), with message type = (0x08, 0x03) and the
 198 payload field used as defined here in [Table 5-1](#)[Table 5-1](#).

Description	Format	Usage	Mandatory	
			For UCM	For SGD
Link ACK	0x06 (a single byte response)	<p>Sent from either the UCM or the SGD to the other in response to a valid message received. Link ACK indicates:</p> <ol style="list-style-type: none"> 1. Message type supported 2. Length valid and 3. CRC good 	✓	✓
Link NAK	0x15, Link NAK Error Code (a two-byte response)	<p>Sent from either the UCM or the SGD to the other in response to an invalid message received.</p> <p>See section 5.1.1 for “Link NAK Error Code” details.</p>	✗	✗
Link NAK	0x15, Link NAK Error Code (a two-byte response)	<p><u>Sent from either the UCM or the SGD to the other in response to an invalid message received.</u></p> <p><u>See section 5.1.1 for “Link NAK Error Code” details.</u></p>	✓	✓

<u>Message Type Support Query</u>	<u>Message Format Per the Serial Protocol (Table 3-1) with no Payload (6 bytes total)</u>	<p>To determine if a Message Type is supported, send:</p> <p><u>MT1, MT2, 0x00, 0x00, CS01, CS02</u> Where MT1 and MT2 identify the message type (see Table 3-2) and CS01, CS02 are the checksum bytes.</p> <p>If the message type is supported, the recipient shall respond with a data-link ACK. If it is not supported, the recipient shall respond with a data-link NAK (error code 0x06)</p>	
<u>Message Type Support Query</u>	<u>Message Format Per the Serial Protocol (Table 3-1) with no Payload (6 bytes total)</u> <u>For this query, the first two bytes (MT1 and MT2) are indicative of the message type being investigated, not "0x08, 0x03".</u>	<p>To determine if a Message Type is supported, send:</p> <p><u>MT1, MT2, 0x00, 0x00, CS01, CS02</u> Where MT1 and MT2 identify the message type (see Table 3-2) and CS01, CS02 are the checksum bytes.</p> <p>If the message type is supported, the recipient shall respond with a data-link ACK. If it is not supported, the recipient shall respond with a data-link NAK (error code 0x06)</p>	
<u>Request Different Power Mode</u>	<u>Message Format Per Basic DR Application</u> (8 bytes total, see Table 6-1) <u>Opcode1 = 0x16</u> <u>Opcode2 = Power Level Indicator</u>	<p>Sent from the UCM to the SGD to request permission to draw higher power than the default.</p> <p>See section 5.1.2 for "Power Level Indicator" details.</p>	
<u>Request Different Power Mode</u>	<u>Message Format Per Basic DR Application</u> (8 bytes total, see Table 6-1) <u>Opcode1 = 0x16</u> <u>Opcode2 = Power Level Indicator</u>	<p>Sent from the UCM to the SGD to request permission to draw higher power than the default.</p> <p>See section 5.1.2 for "Power Level Indicator" details.</p>	

<u>Request Different Bit Rate</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x17</u> <u>Opcode2 = Bit Rate Indicator</u>	<u>Sent from either the UCM or the SGD to the other to request a shift to a higher bit rate.</u> <u>See section 5.1.3 for "Bit Rate Indicator" details.</u>		
<u>Request Different Bit Rate</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x17</u> <u>Opcode2 = Bit Rate Indicator</u>	<u>Sent from either the UCM or the SGD to the other to request a shift to a higher bit rate.</u> <u>See section 5.1.3 for "Bit Rate Indicator" details.</u>		
<u>Query: Maximum payload length?</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x16</u> <u>Opcode2 = 0x00</u>	<u>A query sent from either the UCM or the SGD to the other to ask how long message payloads can be.</u> <u>"Link NAK" means that only the default of 2 payload bytes are supported.</u>		
<u>Query: Maximum payload length?</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x16</u> <u>Opcode2 = 0x00</u>	<u>A query sent from either the UCM or the SGD to the other to ask how long message payloads can be.</u> <u>"Link NAK" means that only the default of 2 payload bytes are supported.</u>		

<u>Response: Maximum data-unit length</u>	<p><u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u></p> <p><u>Opcode1 = 0x19</u> <u>Opcode2 = Max Length Indicator</u></p>	<p><u>Response to an Opcode 0x16 query.</u> <u>Max Length Indicator:</u></p> <p><u>0x00 = 2 (default)</u> <u>0x01 = 4</u> <u>0x02 = 8</u> <u>0x03 = 16</u> <u>0x04 = 32</u> <u>0x05 = 64</u> <u>0x06 = 128</u> <u>0x07 = 256</u> <u>0x08 = 512</u> <u>0x09 = 1024</u> <u>0x0A = 2048</u> <u>0x0B = 4096</u> <u>0x0C = 8192</u> <u>0x0D to 0xFF reserved</u></p>		
<u>Response: Maximum payload length</u>	<p><u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u></p> <p><u>Opcode1 = 0x19</u> <u>Opcode2 = Max Payload Length Indicator</u></p>	<p><u>Response to an Opcode 0x16 query.</u> <u>Max Payload Length Indicator:</u></p> <p><u>0x00 = 2 (default)</u> <u>0x01 = 4</u> <u>0x02 = 8</u> <u>0x03 = 16</u> <u>0x04 = 32</u> <u>0x05 = 64</u> <u>0x06 = 128</u> <u>0x07 = 256</u> <u>0x08 = 512</u> <u>0x09 = 1024</u> <u>0x0A = 2048</u> <u>0x0B = 4096</u> <u>0x0C = 8192</u> <u>0x0D to 0xFF reserved</u></p>		
<u>Query: Get SGD Slot Number</u>	<p><u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u></p> <p><u>Opcode1 = 0x1A</u> <u>Opcode2 = 0x00</u></p>	<p><u>Query sent from the UCM to the SGD to determine which slot the UCM is installed in.</u></p>		

<u>Query: Get SGD Slot Number</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1A</u> <u>Opcode2 = 0x00</u>	<u>Query sent from the UCM to the SGD to determine which slot the UCM is installed in.</u>		
<u>Response: Slot Number</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1B</u> <u>Opcode2 = Slot Number</u>	<u>Response to Opcode 0x1A. Slot Number = a value from 0x00 to 0x0F indicating the slot number in which the UCM is installed.</u>		
<u>Response: Slot Number</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1B</u> <u>Opcode2 = Slot Number</u>	<u>Response to Opcode 0x1A.</u> <u>Slot Number = a value from 0x00 to 0x07 indicating the slot number in which the UCM is installed.</u>		
<u>Query: Get Available Slot Numbers</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1C</u> <u>Opcode2 = 0x00</u>	<u>UCM asking the SGD what slot numbers exist and which are used.</u>		
<u>Query: Get Available Slot Numbers</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1C</u> <u>Opcode2 = 0x00</u>	<u>UCM asking the SGD what slot numbers exist and which are used.</u>		
<u>Response: Available Slot Numbers</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1D</u> <u>Opcode2 = Slot Number Detail</u>	<u>Response to Opcode 0x1C.</u>		
<u>Response: Available Slot Numbers</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1D</u> <u>Opcode2 = Slot Number Detail</u>	<u>Response to Opcode 0x1C.</u> <u>Slot Number Detail = Bit-field:</u> <u>0 = Slot does not exist or is not occupied</u> <u>1 = Slot is occupied</u> <u>Bit 0 (LSbit) = Slot Number 0</u> <u>...</u> <u>Bit 7 (MSbit) = Slot Number 7</u>		

<u>Send Next Command to Slot</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1E</u> <u>Opcode2 = Slot Number</u>	<u>Instructs the SGD to forward the next message to the indicated Slot Number</u>		
<u>Send Next Command to Slot</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x1E</u> <u>Opcode2 = Slot Number</u>	<u>Instructs the SGD to forward the next message to the indicated Slot Number</u> <u>Slot Number = a value from 0x00 to 0x07 indicating the slot number to which the message is to be sent.</u>		

199

Table 5-1 Data Link Command Set

200 **5.1.1 Link NAK Error Codes**201 Link NAKs are two byte messages, the second of which is an error code. These codes are enumerated, 202 defined as indicated in [Table 5-2](#).

Link NAK Error Code	Priority	Description	Usage
0x00		No Reason	Not used.
0x01	1	Invalid Byte	Indicates that a byte framing or other invalid byte error has occurred (e.g. missing stop-bit on the AC RS-485 interface)
0x02	2	Invalid Length	Used to indicate that the length indicated in the PDU length field is out of range
0x03	3	Checksum Error	The bytes in the checksum field at the end of the message did not agree with the computed checksum
0x04	4	Reserved	
0x05	5	Message Timeout	<u>Indicates that more than 500[mS] elapsed between receipt of the first byte and receipt of the last byte in a message transmission. 500mS was selected to allow any combination of data rate and payload in initial draft. As additional speeds and payloads are added some combinations may be invalid. This error code is not used by the DC Form Factor of Appendix A.</u>
0x05	5	Message Timeout	<u>Indicates that more than t_{ML} (defined in Table 3-3) elapsed between receipt of the first byte and receipt of the last byte in a message transmission. t_{ML} was selected to allow any combination of data rate and payload in initial draft. As</u>

			additional speeds and payloads are added some combinations may be invalid. This error code is not used by the DC Form Factor of Appendix A.
0x06	6	Unsupported Message Type	Indicates that the “Message Type” is not supported
0x07	7	Request Not Supported	Indicates that the requested setting is not supported (e.g. a requested Power Mode or Bit Rate is not supported)
0x07	7	Request Not Supported	Indicates that the requested setting is not supported (e.g. a requested Power Mode or Bit Rate is not supported) This error code is used only in regards to link-layer requests, not in regards to lack of support for application layer requests.

203

Table 5-2 Link NAK Error Codes

204 In the event that multiple errors are detected, the Link NAK Error Code with the lowest priority number
205 shall be returned.

206 **5.1.2 Interface Power Limit Negotiation**

207 UCMs may optionally [use](#) this data link function to request that the power consumption limits be
208 changed to the level indicated by the request. The Opcode2 field, Power Level Indicator, is an
209 enumeration:

210

Power Level Indicator	DC Form Factor		AC Form Factor		
	Maximum Continuous Average	Maximum Peak [mA]	Maximum Continuous Average	Maximum Peak	Maximum Instantaneous
0x00 (default)	50[mA]	300[mA]	50 [mA,rms]	100 [mA,rms]	10 [Amps]
0x01	50[mA]	2[Amp]	N/A	N/A	N/A
0x02 to 0xFF (Reserved)					

211

Table 5-3 Interface Power Level Indicator Codes

212 Where:

- 213 • “Maximum Peak” = allowed for a 100[msec] maximum duration with a 10% maximum duty
214 cycle in any given second.

- 215 • “Maximum Instantaneous” = allowed for 1[mS] maximum duration, with a 10% maximum duty
216 cycle in any given 10[mS] period and a 1% maximum duty cycle in any given 10 second period.

217

218 For the DC interface, power is supplied at low voltage DC and for the AC interface, at the AC line voltage,
219 as described in the respective physical layer appendices.

220

221 All UCMs must operate within the default power limits until negotiating a higher power with SGD. It is
222 recognized that wired media UCMs may draw power from their media (PoE, PLC, Telephone) if
223 additional power is required from a separate power supply or interface dongle.

224 This function always results in either a “Link ACK or a “Link NAK” response. “Link ACK” means that the
225 requested power mode is approved. “Link NAK” with Error Code 0x07 means that the requested power
226 mode is not supported.

227 **5.1.3 Bit Rate Negotiation**

228 For the DC form factor, this link layer function establishes the maximum rate at which the SGD may clock
229 the SPI interface. For the AC form factor with the asynchronous RS-485 serial interface, it establishes
230 the bit rate that both the UCM and the SGD must use in order to communicate with one another.
231 Either UCM or SGD may optionally use this data link function to request a different bit rate than the
232 default or current rate.

233

234 The “Bit Rate Indicator” field is defined as:

235

236 0x00 = 19.2[Kbps] (default)

237 0x01 = 38.4[Kbps]

238 0x02 = 57.6[Kbps]

239 0x03 = 115.2[Kbps]

240 0x04 = 256 [Kbps]

241 0x05 = 460.8[Kbps]

242 0x06 = 921.6[Kbps]

243 0x07 = 1843.2[Kbps]

244 0x08 = 3686.4[kbps]

245 0x09 to 0xFF reserved

246

247 If the requested bit rate is supported, “Link ACK” is immediately returned at the original bit rate. Future
248 communication is at the new requested bit rate until such time as the units revert to default or a
249 different bit rate is requested. “Link NAK” with Error Code 0x07 means that the requested Bit Rate is
250 not supported.

251 Note: If no valid communication is exchanged for more than 15 minutes, both SGD and UCM shall return
252 to the default of 19.2[Kbps] [as identified in Section 5.1.5](#).

253 **5.1.4 Message Type support Query**

254 After power-up, communication modules and end devices shall begin communication assuming only
255 that the data-link ACK/NAK and mandatory functions of the “Basic DR” application are supported. This
256 requires the ability to handle only 8 byte messages, parsing of only a short list of payloads (2 required
257 commands), and allows NAK’ing of any unsupported commands.

258 After power-up or upon receipt of a message through its communication network, the UCM may send
259 the Link Layer "Message Type Support Query" to discover what types of advanced message types the
260 appliance or console is capable of supporting.

261 UCMs may be developed with the ability to receive more advanced protocols, like Smart Energy Profile
262 or OpenADR over a network, and then either pass the messages through to the SGD if it supports them,
263 or interpret the messages and translate into “Basic DR”. This interface specification makes no
264 assumptions or requirements of the communication systems themselves.

265

266 **5.1.5 Power-Up and State Reset**

267 Upon power cycle, all operational settings shall return to defaults. Any non-default settings (e.g. bit
268 rate, power level) must be renegotiated following a power cycle.

269 The “Outside Communication Connection Status” message defined in Section 6 requires that a message
270 be sent at least once every 1-5 minutes. If no valid communication is exchanged for more than 15
271 minutes, both SGD and UCM shall return to defaults. This includes returning to the default bit-rate and
272 UCM’s limiting power consumption to the default levels.

273 **6 “Basic DR” Application (Message Type = 0x08, 0x01)**

274 This section defines a set of “Basic DR” application commands and explains how they are supported by
275 the interface. Because these commands are not a reference into another existing specification, they are
276 fully documented here. Understanding the “Basic DR” commands is important, because even advanced
277 communication modules and devices that may normally use more complex protocols, are required to be
278 able to fall back to a few required Basic DR messages in the event that the device to which they are
279 connected is not capable of the same advanced functionality.

280 Each “Basic DR” message shall be formatted as follows, with the message type being a “1” and the
281 payload being a one byte Opcode1 and a one byte Opcode2.

Message Type = 0x08, 0x01	Payload Length = 0x00, 0x02	OpCode 1	OpCode 2	Checksum
------------------------------	-----------------------------------	----------	----------	----------

2 Bytes	2 Bytes	1 Byte	1 Byte	2 Bytes
---------	---------	--------	--------	---------

282

Table 6-1 Basic Application Data Format

283 The Basic DR message payloads are defined as follows:

Description	Opcode1	Opcode2	Usage	for SGDs	Mandatory?
for UCMs					
Shed	0x01	Event Duration	<p>Sent from the UCM to the SGD to when a load shed event begins.</p> <p>If other load management commands are attempted but not accepted by the SGD, then the UCM must fall back to this Opcode.</p> <p>Event Duration: Defined in Section 6.1.2</p> <p>Note: Event Durations of 10 minutes or less relate to “spinning reserve” uses. Event Durations greater than 10 minutes relate to “shift” uses.</p>	✓	✓
Shed	0x01	Event Duration	<p>Sent from the UCM to the SGD to when a load shed event begins.</p> <p>If other load management commands are attempted but not accepted by the SGD, then the UCM must fall back to this Opcode.</p> <p>Event Duration: Defined in Section 6.1.2</p> <p>Note: Event Durations of 10 minutes or less relate to “spinning reserve” uses. Event Durations greater than 10 minutes relate to “shift” uses.</p>	✓	✓
End Shed/Run Normal	0x02	Not Used	Sent once from the UCM to the SGD when a load shed or other curtailment event ends.	✓	✓
Basic Application ACK	0x03	ACK'ed Opcode1	<p>Acknowledge successful receipt and support of previous command.</p> <p>Returned for all supported Opcodes except 0x03 (do not “Application ACK” an “Application ACK”) and those that are queries and have a natural response, such as 0x12.</p>	✓	✓

<u>Basic Application NAK</u>	0x04	<u>Reason</u>	<p>Reject previous command. Sent from either SGD or UCM to the other when any of the following reasons occur.</p> <p>Reason:</p> <ul style="list-style-type: none"> — 0x00 = No reason given — 0x01 = Opcode1 not supported — 0x02 = Opcode2 invalid — 0x03 = Busy — 0x04 to 0xFF Reserved 	✓	✓
<u>Basic Application NAK</u>	0x04	<u>Reason</u>	<p>Reject previous command. Sent from either SGD or UCM to the other when any of the following reasons occur.</p> <p>Reason:</p> <ul style="list-style-type: none"> — 0x00 = No reason given — 0x01 = Opcode1 not supported — 0x02 = Opcode2 invalid — 0x03 = Busy — 0x04 = Length Invalid — 0x05 to 0xFF Reserved 	✓	✓
Request for Power Level	0x06	<u>Percent Setting</u>	<p>Sent from the UCM to the SGD to request that its average power level (relative to the full rating of the device) be reduced to a level between 0 and 100% of full value on a 7-bit precision scale.</p> <p>Percent Setting:</p> <p>MSbit = 0, Least significant 7 bits:</p> <ul style="list-style-type: none"> — 0x00 to 0x7F = 0 to 100% power absorbed <p>MSbit = 1, Least significant 7 bits:</p> <ul style="list-style-type: none"> — 0x00 to 0x7F = 0 to 100% power produced <p>Details regarding the use of this command are provided in Section 6.2.1</p>		

<u>Request for Power Level</u>	0x06	<u>Percent Setting</u>	<p><u>Sent from the UCM to the SGD to request that its average power level (relative to the full rating of the device) be reduced to a level between 0 and 100% of full value on a 7bit precision scale.</u></p> <p><u>Percent Setting:</u> <u>MSbit = 0, Least significant 7 bits:</u> <u>0x00 to 0x7F = 0 to 100% power absorbed</u> <u>MSbit = 1, Least significant 7 bits:</u> <u>0x00 to 0x7F = 0 to 100% power produced</u></p> <p><u>Details regarding the use of this command are provided in Section 6.2.1</u></p>		
Present Relative Price	0x07	Relative Price Indicator	<p>Sent from the UCM to the SGD when a change in relative price occurs to inform of the new relative price.</p> <p>Relative Price Indicator: See Section 6.2.2 for description and usage</p> <p>If NAK'ed, UCM must use Opcodes 0x01 and 0x02 to inform SGDs.</p>		
Next Period Relative Price	0x08	Relative Price Indicator	<p>Sent from the UCM to the SGD when a change in relative price occurs to inform of the relative price in the next future period.</p> <p>Relative Price Indicator: See Section 6.2.2 for description and usage</p>		
<u>Time Remaining in Present Price Period</u>	0x09	<u>Event Duration</u>	<p><u>Sent from the UCM to the SGD when a change in price occurs to inform of the duration of the present price period.</u></p> <p><u>Event Duration: Defined in Section 6.1.2</u></p>		
<u>Time Remaining in Present Price Period</u>	0x09	<u>Event Duration</u>	<p><u>Sent from the UCM to the SGD when a change in price occurs to inform of the duration of the present price period.</u></p> <p><u>Event Duration: Defined in Section 6.1.2</u></p>		
Critical Peak Event	0x0A	Event Duration	<p><u>Critical Peak Event is in Effect (few times a year, 5 hours max) Sent once from the UCM to the SGD when a critical peak price event goes into effect. If NAK'ed, send Opcode 0x01.</u></p> <p><u>Event Duration: Defined in Section 6.1.2</u></p>		

<u>Critical Peak Event</u>	<u>0x0A</u>	<u>Event Duration</u>	<p><u>Critical Peak Event is in Effect (Critical Peak Events are intended to represent events that occur only a few times per year, on system peak days, for a maximum duration determined by the terms of the program) Sent once from the UCM to the SGD when a critical peak price event goes into effect. If NAK'ed, send Opcode 0x01.</u></p> <p><u>Event Duration: Defined in Section 6.1.2</u></p>		
<u>Grid Emergency</u>	<u>0x0B</u>	<u>Event Duration</u>	<p><u>A Grid Emergency is occurring. Sent once from the UCM to the SGD when a grid emergency event goes into effect. If NAK'ed, send Opcode 0x01.</u></p> <p><u>Event Duration: Same as for Opcode 0x01</u></p>		
<u>Grid Emergency</u>	<u>0x0B</u>	<u>Event Duration</u>	<p><u>A Grid Emergency is occurring. Sent once from the UCM to the SGD when a grid emergency event goes into effect. If NAK'ed, send Opcode 0x01.</u></p> <p><u>Event Duration: Defined in Section 6.1.2</u></p>		
Grid Guidance	0x0C	Guidance Indicator	<p>Sent from the UCM to the SGD to provide an arbitrary indication of whether energy consumption is preferred or not.</p> <p>Guidance Indicator:</p> <p>0x00 = Bad Time to Use Energy 0x01 = Neutral 0x02 = Good/ Preferred Time to Use Energy 0x03 to 0xFF = Reserved</p>		
Outside Comm Connection Status	0x0E	Connect Status Code	<p>Sent from the UCM to the SGD when outside communication status is gained or lost. When in the “communicating” state, this command is resent every 1 to 5 minutes so that SGD’s may know that the UCM is still attached and working.</p> <p>Connect Status Code:</p> <p>0x00 = No / Lost Connection 0x01 = Found / Good Connection 0x02 = Poor / Unreliable Connection 0x03 to 0xFF = Reserved</p>	✓ If known it must be shared	

Customer Override	0x11	Not Used	Sent from the SGD to the UCM when a customer chooses to override any load reduction process. Also sent immediately after acknowledging receipt of any load reduction message if the customer's preference is permanently set to override.		
Query: What is your operational state?	0x12	Not Used	Sent from the UCM to the SGD.		
<u>State Query Response</u>	<u>0x13</u>	<u>Operating State Code</u>	<u>Sent from the SGD to the UCM in response to an Opcode 0x12 query</u> <u>Operating State Codes:</u> <u>(See description in section 6.2.4)</u>		
<u>State Query Response</u>	<u>0x13</u>	<u>Operating State Code</u>	<u>Sent from the SGD to the UCM in response to an Opcode 0x12 query</u> <u>Operating State Codes:</u> <u>(See description in section 6.2.4)</u>		
Sleep	0x14	0x00	Sent from the SGD to the UCM to inform it that the SGD is idle, that information from the UCM is not needed, and that the UCM may shift into a low power state, if exists. This command assumes that the UCM will be provided with a "wake" command before it will be expected to operate. Usage assumes the UCM can hear "wake" messages while in "sleep" mode.		
<u>Wake / Refresh Request</u>	<u>0x15</u>	<u>0x00</u>	<u>Sent from the SGD to the UCM to end a "Sleep" period and to request that all messages related to currently valid connection status, price, time, and/or load curtailment be sent.</u>		
<u>Wake / Refresh Request</u>	<u>0x15</u>	<u>0x00</u>	<u>Sent from the SGD to the UCM to end a "Sleep" period and to request that all messages related to currently valid connection status, price, time, and/or load curtailment be sent.</u> <u>UCM's that previously received a "Sleep" message are required to provide up-to-date grid information within 10 seconds of receipt of a "Wake" signal. How UCMs function internally during Sleep periods in order to be able to support this capability is up to the UCM provider.</u>		

Simple Time Sync	0x16	Time Value	When supported, this command is sent from the UCM to the SGD on the hour. Time Value: Bits 7..5 = Weekday (0 = Sunday, 6 = Saturday) Bits 4..0 = Hour of Day (0 to 23)		
------------------	------	------------	---	--	--

284

Table 6-2 Basic DR Application Command Set

285 After power-up, communication modules and end devices shall begin communication assuming only
 286 that the data-link ACK/NAK and mandatory functions of the “Basic DR” application are supported. This
 287 requires the ability to handle only 8 byte messages, parsing of only a short list of payloads (2 required
 288 commands), and allows NAK’ing of any unsupported commands.

289 After power-up or upon receipt of a message from the outside world, the UCM may send Opcode 0x15
 290 queries to discover what types of advanced message types the appliance or console is capable of
 291 supporting. Alternatively, it could just figure it out by trying and getting ACK’ed/NAK’ed.

292 UCMs may be developed with the ability to receive more advanced protocols, like Smart Energy Profile
 293 or OpenADR over a network, and then either pass the messages through to the SGD if it supports them,
 294 or interpret the messages and translate into “Basic DR”. This interface specification makes no
 295 assumptions or requirements of the communication systems themselves.

296 **6.1.1 Basic Message Fixed Length**


297 The “Basic DR Application” messages are fixed at 8 bytes total length, because the payload always
 298 consists of two bytes. This makes message parsing simple because processors can shift over a known
 299 number of bytes and always find the field of interest.

300 **6.1.2 Event Duration Field**

301 Basic DR Opcode1’s 0x01, 0x09, 0x0A and 0x0B include a secondary Opcode2 that is an Event Duration
 302 indicator. This indicator is a single byte that defines the duration (or remaining duration) of the present
 303 event or price period. The value of 0x00 is reserved to indicate that the Event Duration is unknown and
 304 the value of 0xFF indicates that the duration is longer than what can be represented. For values from
 305 0x01 to 0xFE, the indicated time is defined by a square function of the byte value:

306 $\text{Time in Seconds} = 2 * (\text{Byte Value})^2$

307 This results in the ability to represent a range of Event Durations between 0 and 129032 seconds
 308 (approximately 35.8 hours) as indicated in [Figure 6-1](#).



309

310

Figure 6-1 Non-Linear Event Duration Scaling311 **6.1.3 Grouped Messages**

312 The Basic DR messages carry little information due to their length limit of two payload bytes. As a
 313 result, some groups of Basic DR messages may be thought-of as a grouped set, such as Opcodes 0x07,
 314 0x08, and 0x09 (in any combination) sent from the UCM to the SGD to represent relative price
 315 information. In these cases, all the related messages in the group must be sent in rapid succession
 316 within the timeframe specified in [Table 3-3](#).

317 **6.2 Usage and Details of Basic DR Application Messages**318 **6.2.1 Request for Power Level (Opcode 0x06)**

319 Used by the service provider to ask suitable loads to provide ancillary service to the grid such as
 320 frequency support, in-hour load following, etc. Typical signal changes could occur as often as every 5
 321 minutes in some scenarios or every few seconds in others. The mechanism used by the end device to
 322 respond (e.g. analog variability, adjustable regulator, or PWM duty cycling) is up to the manufacturer of
 323 the SGD and is not specified by this request. Examples: A water heater's bottom heating element,
 324 instead of operating at 4500 watts, could be managed at certain times of day to operate ~~900 watt (20%)~~
 325 ~~nominal average power. But at 900 watt (20%). This setting could be modified rapidly in order to~~
 326 compensate for ~~wind power generation variation, in one 5 min variable generation sources period the~~
 327 ~~request could be for 1500 watt (33%) avg. power wind is blowing harder and in the next 5 minute period~~
 328 ~~300 watt (7%) when wind lets up. Battery chargers could change rates to accommodate this request.~~

329 | ~~Electric dryers, in some cases, could operate the heating elements at a reduced average power level. A~~
330 | ~~smart pool or well pump could respond easily, such as wind power.~~

331 | ~~The~~During usage, the UCM relays the command to SGD; Application ACKs and NAKs from SGD may be
332 | conveyed upstream to Service Provider, if applicable.

333 | For SGDs, loads that will operate at approximately the requested average power level shall ACK this
334 | command; under all other conditions a NAK should be provided. An appliance for all sorts of reasons
335 | might be able to comply at some times and not at others, e.g. exceeding the number of design relays
336 | cycles permitted per day. ACKs shall be reserved for those instances where ~~a reduction in the target setting~~
337 | is actually made applied.

338 | **6.2.2 Relative Price Commands (Opcode 0x07 and 0x08)**

339 | The relative price commands are intended for use in variable-price systems wherein the UCM is able to
340 | provide to the SGD with an indication of the ratio of the current price to the average price. As indicated
341 | in [Table 4.2](#), [Table 6-2](#), the Opcode2 field of these messages ([Opcodes 0x07 and](#) [Opcode 1 = 0x07 or](#)
342 | 0x08) provides the relative price indicator.


343 |
$$\text{Relative_Price_Indicator} = \text{Present_Price} / \text{Average_Price}$$

344 | Where "Average_Price" is calculated as defined in Appendix E.

345 | The value of 0x00 is reserved to indicate that the Relative Price is unknown and the value of 0xFF
346 | indicates that the Relative Price is higher than what can be represented. For values from 0x01 to 0xFE,
347 | the indicated Relative Price Indicator is defined by a nonlinear function of the byte value:

348 |
$$\text{Relative_Price_Indicator} = (\text{Byte Value}-1) * (\text{Byte Value} + 63) / 8192$$

349 | This equation results in the scale indicated in [Figure 6-1](#)[Figure 6-1](#)[Figure 6-2](#)[Figure 6-2](#).



350

Figure 6-2 Non-Linear Relative Price Scaling

352 For SGD's the "Relative_Price_Indicator" may be simply used directly as an indication of how high or low
 353 the energy price for the period is relative to normal. As a simple ratio, it may be directly converted to
 354 percentages for customer presentation or preference settings.

355 The intent of the Opcode 0x07 is that it be sent from the UCM to the SGD at the beginning of each new
 356 price period. It reflects the price that has just become effective. The intent of the Opcode 0x08 is to
 357 provide a forward-looking indication of the relative price in the next future period. If available [and](#)
 358 supported, UCM's should attempt to provide SGDs with both the present (0x07) and next (0x08)
 359 indicators. SGD's may support neither, one, or both, at their discretion.

360 Note: Actual price information is supported through the use of more advanced commands as described
 361 in Section [9](#)—of this document.

362 **6.2.3 Time Remaining in Present Price Period (Opcode 0x09)**

363 This command is related to the Relative Price Messages and provides an indication of the time
 364 remaining until the next price change. When supported, this command must be sent once from the
 365 UCM to the SGD when a new relative price becomes effective or when a refresh is requested by the
 366 SGD.

367 [This "Time Remaining in Present Period" message may be of most value when used in conjunction with](#)
 368 [the "Next Period Relative Price" message so that end devices know whether the price is increasing or](#)
 369 [decreasing at the end of this period.](#)

370 **6.2.4 Operating State Monitoring (Opcodes 0x12 and 0x13)**

371 Opcode 0x12 requests the operational state of the SGD and Opcode 0x13 provides the response. The
372 Opcode 0x13 response includes a single byte Opcode2 that describes the state of the device. The
373 following may be extended in future versions. Up to 255 states may be defined.

Operating State Code	Meaning
0	Idle Normal
1	Running Normal
2	Running Curtailed Grid
3	Running Heightened Grid
4	Idle Grid
5	SGD Error Condition
6-255	Unused

374 **Figure 4.5Table 6-3 – Operating State Codes**

- 375 Op State Code 0 “Idle Normal” indicates a low power state, including user-operated devices that are
376 not presently being used and automatically-operated devices that are in a standby
377 state. Examples include a clothes dryer that is not operating, a refrigerator in idle
378 mode (any time the compressor is not running), a water heater without a heating
379 element energized, a TV in standby mode, etc.
- 380 Op State Code 1 “Running Normal” means that the SGD is operating in any normal mode or process.
381 This includes user-operated devices that are presently being used (e.g. a washing
382 machine that is in any cycle of the washing process including “soak”, an oven that is
383 maintaining a set temperature even if the element is off at the moment, etc.) as well
384 as automatically-operated equipment that is currently active (e.g. an HVAC unit that
385 is presently running, a water heater with heating element energized, etc.)
- 386 Op State Code 2 “Running Curtailed Grid” the SGD is running, but has responded per some grid signal
387 and has reduced average power relative normal or unrestricted operation. For
388 example, a dryer may cycle the heating element in some way to reduce average
389 power, or a refrigerator may stop the compressor or raise the temperature setting
390 etc. An SGD, such as a stove top, may respond to an emergency curtailment for only
391 one minute; if the state-query comes during this minute then the response would be
392 state code 2. If the state query comes after the normal control method resumes
393 then the state code response would be 1.
- 394 Op State Code 3 “Running Heightened Grid” means that the SGD has responded to a grid signal and
395 has increased average power relative to normal or unrestricted operation. Common
396 examples may be: 1) an HVAC or refrigerator consuming more average power

397 (putting additional heat or cold into building, tank, or other thermal mass) in
398 response to lower price or a more specific control command. 2) SGD operating in a
399 grid friendly mode and using more average power. Grid friendly mode applies to
400 SGDs that have flexibility to operate over a wide range of average power levels at
401 times not constrained by customer demands. (e.g. a water heater maximizing water
402 temperature at night, or an EV charging its battery at night.)

403 Op State Code 4 “Idle Grid” means that the SGD has stopped (reduction to lowest consumption state)
404 or is deferring consumption to a later time, in response to a grid signal. This state is
405 different from OpState Code 1 because OpState Code 4 implies that the SGD would
406 be operating were it not for the grid signal. Whereas OpState Code 2 is used to
407 indicate some level of partial reduced consumption, OpState Code 4 indicates full
408 reduction to Idle level.

409 Op State Code 5 SGD Inoperable: SGD is not operating because it needs maintenance support or is in
410 some way disabled (i.e. not a response to the grid)

411 ***6.2.5 Advanced Notice of Price/Curtailment Increase or Decrease (Opcodes 0x0C and 0x0D)***

412 ~~These commands are used by a UCM to inform an SGD of how long the current condition is expected to~~
413 ~~continue, and whether the condition to follow is to be more or less attractive for energy consumption.~~
414 ~~UCMs that have knowledge of this information shall support this command and attempt to provide the~~
415 ~~information to SGDs. Likewise, SGDs that may take any action in regard to this information shall support~~
416 ~~this command and ACK accordingly.~~

417 ~~When used, these advanced notice commands shall be sent once per minute, at or about the whole~~
418 ~~minute.~~

419 ~~Only the next condition is to be indicated. For example, if a UCM knows that a curtailment period is~~
420 ~~starting in 10 minutes, and ending in 70 minutes, it shall send only the Increase (Opcode 0x0C)~~
421 ~~command until such time as the curtailment period is in effect, after which the UCM shall begin sending~~
422 ~~the Decrease (Opcode 0x0D) command.~~

423 **7 Intermediate DR Application (Message Type = 0x08, 0x02)**

424 This section identifies intermediate commands to support more advanced functions. Unlike the Basic
425 DR Application message set, which is fixed at 8 bytes total message length, Intermediate DR application
426 messages have variable lengths. For those messages identified in this section that are longer than 8
427 bytes, affirmative response that the Intermediate DR message type is supported implies that the
428 maximum Intermediate DR packet length can be accepted. In other words, this specification prohibits
429 transfer of serial messages that would overflow buffers of the recipient.

430 Intermediate DR commands are all optional. Where the terms “optional” and “mandatory” are used in
431 the tables in this section, they refer only to the requirement for those fields within the message being
432 described. Intermediate DR commands follow the protocol data unit format indicated in [Table 3-1](#)[Table 3-1](#)
433 [Table 7](#)[Table 7](#), with the “Payload” field used as defined in [Table 7](#)[Table 7](#) and Table 7-2.

434 Fields designated as Signed values use Two’s Compliment format. The signed 8-bit value -5 would be
435 encoded as 0xFB, The signed 16 bit value -1 would be encoded as 0xFFFF.

436 Table 7.1 provides a list of the categories for the messages defined in this section. The Opcode1 column
437 refers to the first byte (most significant byte) of the payload section as described in table 3.1 (protocol
438 data unit format).

Opcode1	Usage Categories
0x00	Reserved
0x01	Device Information
0x02	Time & Date
0x03	Tier & Price
0x04	Demand Reduction
0x05	Demand Response Event Schedules
0x06	Home Consumption/Production
0xF0-0xFF	Manufacturer Specific

439 **Table 7-1 Intermediate DR Application Command Set (Command Byte Description)**

440 Table 7.2 provides a more granular list of the messages defined in this section.

Description	Payload			Usage
	OpCode1	OpCode2	Additional Payload Definitions	
Info Request	0x01	0x01	Defined in section 7.1.1	Request device information
Get/Set UTC Time	0x02	0x00	Defined in section 7.1.2	Set or request Time
Get/Set Energy Price	0x03	0x00	Defined in section 7.1.3	Set or request the current price of energy
Get/Set Tier	0x03	0x01	Defined in section 7.1.4	Set or request the current tier value

<u>Get/Set Temperature Offset</u>	<u>0x03</u>	<u>0x02</u>	<u>Defined in section 7.1.5</u>	<u>Set or request the current temperature offset value</u>
<u>Get/Set Temperature Offset</u>	<u>0x03</u>	<u>0x02</u>	<u>Defined in section 7.1.5</u>	<u>Set or request the current temperature offset value</u>
<u>Get/Set SetPoint</u>	<u>0x03</u>	<u>0x03</u>	<u>Defined in section 7.1.6</u>	<u>Set or request the current temperature set point value(s)</u>
<u>Get/Set SetPoint</u>	<u>0x03</u>	<u>0x03</u>	<u>Defined in section 7.1.6</u>	<u>Set or request the current temperature set point value(s)</u>
Start Autonomous Cycling	0x04	0x00	Defined in section 7.1.7	Start a Demand Reduction cycling event per the parameters passed in the command
Terminate Autonomous Cycling	0x04	0x01	Defined in section 7.1.8	Terminate a Demand Reduction cycling event
Get/Set Temperature Offset	0x05	0x00	Defined in section Error! Reference source not found.	Set or request the current temperature offset value
Demand Response Event Schedules	0x06	0x00	Defined in section 7.2.1	Send Scheduled Events Request

441

Table 7-2 Intermediate DR Application Command Set

442 Intermediate DR message responses include a response code byte. Table 7.3 provides a list of the
 443 defined response codes.

Response Code	Description
0x00	Success
0x01	Command not implemented
0x02	Bad Value – one or more values in the message are invalid

0x03	Command Length Error – command is too long
0x04	Response Length Error – response is too long

444

Table 7-3 Response Code Values

445 7.1 Usage and Details of Intermediate DR Application Messages

446 7.1.1 Info Request

447 This command may be optionally used by the UCM to determine information about the SGD and by the
448 SGD to determine information about the UCM.

449 7.1.1.1 Format GetInformation() – Request

Byte	Hex value	Comments	Mandatory/ Optional
1	0x01	OpCode1	M
2	0x01	OpCode2	M

450 7.1.1.2 Format GetInformation() - Reply

Byte	Hex value	Comments	Mandatory/ Optional
1	0x01	OpCode1	M
2	0x81	OpCode2 (Reply always has bit 7 high)	M
3	0x00	Response Code	M
4	0x02	Interface Specification Major Version	M
5	0x00	Interface Specification Minor Version	M
6-7		Vendor ID	M
8-9		Device Type	M
10-11		Device Revision	M
12-15		Capability Bitmap	M
16		Reserved	M
17-32		Model Number – UTF-8	O
33-48		Serial Number – UTF-8	O
49		Firmware Year – 20YY	O
50		Firmware Month	O
51		Firmware Day	O
52		Firmware Major	O
53		Firmware Minor	O

451

452 Device Information included here is read-only and will not change after the device has been powered on
453 (i.e. this value may be read once at power-on with confidence that there is no need to read it again until
454 a subsequent reset or power cycle). Typical values included in the device information command include
455 the interface specification version that the unit was designed for, firmware information, Serial Number
456 and Model Number.

457 Vendor ID
458 Vendors who support this command must request a unique vendor ID provided by the standard
459 development organization or users alliance.

460 Device Type

SGD Device Types		UCM Device Types (Phy/MAC)	
Device Type	Description	Device Type	Description
0x0000	Unspecified Type	0x4000	Wireless (other, non-standard)
0x0001	Water Heater - Gas	0x4001	PLC (other, non-standard)
0x0002	Water Heater - Electric	0x4002	Wired (other, non-standard)
0x0003	Water Heater – Heat Pump	0x4003	IEEE 802.15.4
0x0004	Central AC – Heat Pump	0x4004	IEEE 802.11 (e.g. Wi-Fi)
0x0005	Central AC – Fossil Fuel Heat	0x4005	IEEE 802.16 (e.g. WiMAX)
0x0006	Central AC – Resistance Heat	0x4006	VHF/UHF Pager
0x0007	Central AC (only)	0x4007	FM (RDS / RBDS)
0x0008	Evaporative Cooler	0x4008	Wired Ethernet
0x0009	Baseboard Electric Heat	0x4009	Coaxial Networking
0x000A	Window AC	0x400A	Telephone Line
0x000B	Portable Electric Heater	0x400B	IEEE 1901 (BPL)
0x000C	Clothes Washer	0x400C	IEEE 1901.2 (Narrowband-PLC)
0x000D	Clothes Dryer - Gas	0x400D	ITU-T G.hn
0x000E	Clothes Dryer - Electric	0x400E	ITU-T G.hnem (Narrowband-PLC)
0x000F	Refrigerator/Freezer	0x400F	Cellular (Mobile, any)
0x0010	Freezer	0x4010	Utility AMI, Wireless
0x0011	Dishwasher	0x4011	Utility AMI, PLC
0x0012	Microwave Oven	0x5000	Gateway Device
0x0013	Oven – Electric		
0x0014	Oven – Gas	All others	Available for Assignment
0x0015	Cook Top – Electric		
0x0016	Cook Top - Gas		
0x0017	Stove – Electric		
0x0018	Stove - Gas		
0x0019	Dehumidifier		

SGD Device Types		UCM Device Types (Phy/MAC)	
Device Type	Description	Device Type	Description
<u>0x0020</u>	<u>Fan</u>		
0x0030	Pool Pump – Single Speed		
0x0031	Pool Pump – Variable Speed		
0x0032	Electric Hot Tub		
0x0040	Irrigation Pump		
0x1000	Electric Vehicle		
0x1001	Hybrid Vehicle		
0x2000	In Premises Display		
0x8000 – 0xFFFF	Manufacturer Defined Device Types		

461

462 Capability Bitmap

Bit (2^n)	Description
0	Cycling supported
1	Tier mode supported
2	Price mode supported
3	Temperature Offset supported
4-15	Reserved

463 Model Number

464 Device model number, all zeros = not supported

465 Serial Number

466 Device serial number, all zeros = not supported

467 Firmware Year

468 Year – 2000 (e.g. Firmware Year = 11 (0x0B) for 2011).

469 Firmware Month

470 0 (0x00) = January, 11 (0x0B) = December.

471 Firmware Day

472 1 - 31

473 **7.1.2 Get/Set UTC Time**

474 Set the time on the device.

475 [7.1.2.1 Format GetUTCTime\(\) - Request](#)

Payload Byte	Hex value	Comments	Mandatory/ Optional
1	0x02	OpCode1	M
2	0x00	OpCode2	M

476 [7.1.2.2 Format GetUTCTime\(\) - Example reply](#)

Payload Byte	Hex value	Comments	Mandatory/ Optional
1	0x02	OpCode1	M
2	0x80	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M
4-7		UTC Seconds	M
8		Time zone offset in 1/4 hours (e.g. EST = -20)	M
9		DST Offset in 1/4 hours	M

477 [7.1.2.3 Format SetUTCTime\(\) - Request](#)

Payload Byte	Hex value	Comments	Mandatory/ Optional
1	0x02	OpCode1	M
2	0x01	OpCode2	M
2	0x00	OpCode2	M
3-6		UTC Seconds	M
7		Time zone offset in 1/4 hours (e.g. EST = -20)	M
8		DST Offset in 1/4 hours	M

478 [7.1.2.4 Format SetUTCTime\(\) - Example reply](#)

Payload Byte	Hex value	Comments	Mandatory/ Optional
1	0x02	OpCode1	M
2	0x81	OpCode2 (Reply always has bit 7 high)	M
2	0x80	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M

479

480 [UTC Seconds](#)

481 Unsigned 32 bit value of seconds since 1/1/2000 00:00:00 UTC

482 [Time Zone Offset](#)

483 Signed 8 bit value, offset from UTC in 15 minute intervals (e.g. EST would be -20 (0xEC))

484 DST Offset

485 Unsigned, if non-zero, add value in 15 minute intervals to UTC seconds for local time conversion

486 **7.1.3 Get/Set Energy Price**

487 7.1.3.1 Format GetEnergyPrice() - Request

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x00	OpCode2	M

488 7.1.3.2 Format GetEnergyPrice()- Example reply from UCM

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x80	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M
4-5		Current Price	M
6-7		Currency Code	M
8		Digits After Decimal Point	M
9-12		Expiration Time/Date in UTC seconds	O
13-16		Next Price	O

489 7.1.3.3 Format SetEnergyPrice() - Request

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x00	OpCode2	M
3-4		Current Price	M
5-6		Currency Code	M
7		Digits After Decimal Point	M
8-11		Expiration Time/Date in UTC seconds	O
12-15		Next Price	O

490 7.1.3.4 Format SetEnergyPrice()- Example reply from SGD

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x80	OpCode2 (Reply always has bit 7 high)	M

3		Response Code	M
---	--	---------------	---

491 Current Price

492 Unsigned 32 bit value.

493 Currency Code

494 Unsigned 32 bit value, see ISO 4271, US Dollar = 840, Euro = 978, Mexican Peso = 484, Canadian Dollar = 124. The codes can be found on the Web site of the ISO 4217 Maintenance agency, SNV - SIX Interbank
 495 Clearing (http://www.currency-iso.org/iso_index/iso_tables/iso_tables_a1.htm).

497 Digits After Decimal Point

498 Unsigned, the number of digits after the decimal point (e.g 22¢ = 0.22 dollars so the Digits after decimal point value would be 2).

500 Expiration Time/Date

501 Unsigned 32 bit value of seconds since 1/1/2000 00:00:00 UTC

502 Next Price

503 The price that takes affect when the current time reaches the Expiration Time/Date

504 **7.1.4 Get/Set Tier**

505 7.1.4.1 Format GetTier() - Request

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x01	OpCode2	M

506 7.1.4.2 Format GetTier()- Example reply from SGD

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x81	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M
4		Current Tier (0 – 6, 255 = no tier)	M
5-8		Expiration Time/Date in UTC seconds	O
9		Next Tier	O

507 7.1.4.3 Format SetTier() - Request

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x01	OpCode2	M
3-4		Current Tier (0 – 6, 255 = no tier)	M

5-8		Expiration Time/Date in UTC seconds	O
9-10		Next Tier	O

508 [7.1.4.4 Format SetTier\(\)- Example reply from UCM](#)

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x81	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M

509 [Current Tier](#)

510 0 to 6, 255 = no active tier

511 [Expiration Time/Date](#)

512 Unsigned 32 bit value of seconds since 1/1/2000 00:00:00 UTC

513 [Next Tier](#)

514 Tier that takes effect when the expiration time/date is reached

515 [7.1.5 Get/Set Temperature Offset](#)

516 [7.1.5.1 Format GetTemperatureOffset\(\) - Request](#)

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x02	OpCode2	M

517 [7.1.5.2 Format GetTemperatureOffset\(\)- Example reply from SGD](#)

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x82	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M
4		Current Offset	M
5		Units	M

518 [7.1.5.3 Format SetTemperatureOffset\(\) - Request](#)

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x02	OpCode2	M
3		Current Offset	M
4		Units	O

519 7.1.5.4 Format SetTemperatureOffset()- Example reply from UCM

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x81	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M

520 Current Offset

521 Unsigned 8 bit value. Offset to apply to the normal operating temperature in degrees

522 Units

523 0 = degrees F, 1 = degrees C

524 **7.1.6 Get/Set Set Point**525 7.1.6.1 Format GetSetPoint() - Request

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x03	OpCode2	M

526 7.1.6.2 Format GetSetPoint()- Example reply

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x83	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M
4-5		Device Type	M
6		Units	M
7-8		Set Point 1	M
9-10		Set Point 2	O

527 7.1.6.3 Format SetSetPoint() - Request

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x03	OpCode1	M
2	0x03	OpCode2	M
3-4		Device Type	M
5		Units	M
6-7		Set Point 1	M
8-9		Set Point 2	O

528 7.1.6.4 Format SetSetPoint()- Example reply

Payload Byte	Hex value	Comments	Mandatory/ Optional
1	0x03	OpCode1	M
2	0x83	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M

529

530 Device Type

531 See Info Request (Section 7.1.1) for Device Type table. For Set command, packet is ignored if the device
532 type doesn't match the SGD's device type.

533 Units

534 0 = degrees F, 1 = degrees C

535 Set Point 1

536 Signed 16 bit value. First temperature value, 0x8000 (-32768) = don't change (set)/not supported (get).
537 For Water Heaters, Top Element set point. For Thermostats, Heat set point. For Refrigerator/Freezer,
538 Refrigerator set point.

539 Set Point 2

540 Signed 16 bit value. Second temperature value, 0x8000 = don't change (set)/not supported (get). For
541 Water Heaters, Bottom Element set point. For Thermostats, Cool set point. For Refrigerator/Freezer,
542 Freezer set point.

543 7.1.7 *Automomous Cycling*

544 7.1.7.1 Format StartCycling() - Request

Payload Byte	Hex value	Comments	Mandatory/ Optional
1	0x04	OpCode1	M
2	0x00	OpCode2	M
3-6		Event ID	M
7-10		Start Time UTC seconds since 1/1/2000	M
11-12		Duration in minutes	M
13		Duty Cycle	M
14		Start Randomization in minutes	O
15		End Randomization in minutes	O
16		Criticality	O

545 7.1.7.2 Format StartCycling()- Example reply from SGD

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x04	OpCode1	M
2	0x80	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M

546 Event ID

547 Unsigned 32 bit value control event identifier

548 Start Time

549 Unsigned 32 bit value of seconds since 1/1/2000 00:00:00 UTC, 0 = Now

550 Duration

551 Duration of the control event in minutes

552 Duty Cycle

553 % reduction of the load (e.g. 75 means that the device will be off ¼ of the time)

554 Start Randomization

555 The start of the control will be delayed by this randomized value in minutes. The start randomization does not change the duration of the event.

557 End Randomization

558 The event duration will be lengthened by this random value.

559 Criticality

560 Reserved for future use.

561 7.1.8 Demand Reduction - Terminate Cycling562 7.1.8.1 Format TerminateCycling() - Request

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x04	OpCode1	M
2	0x01	OpCode2	M
3-6		Event ID	M
4		End Randomization in minutes	O

563 7.1.8.2 Format TerminateCycling()- Example reply from SGD

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x04	OpCode1	M
2	0x81	OpCode2 (Reply always has bit 7 high)	M
3		Response Code	M

564 [Event ID](#)
 565 Unsigned 32 bit value control event identifier

566 [End Randomization](#)
 567 Continue the control for random value time to prevent large groups from turning on at the same time.

568 7.2 Demand Response Event Schedules

569 Allows for displaying information about demand response events duration, %shed, etc

570 7.2.1 Send Scheduled Events Request

571 7.2.1.1 Format SendScheduledEvents Request (from SGD)

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x50	OpCode1	M
2	0x01	OpCode2	M
4		MSB Start Time (UTC)	M
5		...	M
6		...	M
7		LSB Start Time (UTC)	M
8		UINT8 Number of Events	M

572 7.2.1.2 Format SendScheduledEvents Reply (from UCM)

Payload Byte	Hex value	Comments	Mandatory/Optional
1	0x50	OpCode1	M
2	0x81	OpCode2 (Reply bit always has bit 7 high)	M
4		Response Code	M

573 **8 Commissioning and Network Messages (Message Type = 0x08, 0x04)**
 574 These commands are all optional. The format for these messages is as identified in [Table 3-1](#),
 575 with the payload as identified in [Table 8-1](#). For those messages identified in this section that
 576 are longer than 8 bytes, it is required that the “Maximum Data Unit Length” query defined in the data-
 577 link section be used first. In other words, this specification prohibits transfer of serial messages that
 578 could overflow buffers of the recipient. Unless indicated otherwise, when referenced in this section,
 579 “ACK” and “NAK” refer to the Basic DR Application ACK and NAK.

	Payload			
Description	OpCode1	Opcode2	Additional Payload	Usage

Set Network ID	0x01	0x00 = LAN 0x01 = WAN	Network ID String	Sent to the UCM, from either the SGD or any other configuration/commissioning tool to which it is connected Network ID String: 1 to 120 Bytes, ASCII encoded NAK means that the UCM does not accept Network IDs.
Set User ID	0x02	0x00 = LAN 0x01 = WAN	User ID String	Sent to the UCM, from either the SGD or any other configuration/commissioning tool to which it is connected. User ID String: 1 to 120 Bytes, ASCII encoded NAK means that the UCM does not accept User IDs.
Set Password	0x03	0x00 = LAN 0x01 = WAN	Password String	Sent to the UCM, from either the SGD or any other configuration/commissioning tool to which it is connected. Password String: 1 to 120 Bytes, ASCII encode NAK means that the UCM does not accept Passwords.
Join Network	0x04	0x00	None	Set to the UCM to instruct it to join the network for which it is configured
Leave Network	0x05	0x00	None	Set to the UCM to instruct it to leave the network to which it is currently connected

580

Table 8-1 Commissioning and Network Messages

581 **9 Pass-Through of Standard Protocols**

582 In its simplest mode of operation, this modular communication interface provides for physical layer
 583 diversity and allows application layer (and network layer) protocols that are used in the communication
 584 system to pass through directly to the end device. In such a mode of operation, the UCM need not
 585 understand the content of the messages or parse them in any way. In order for this to work, the end
 586 device must be capable of accepting and understanding the protocol that is passed through.

587 This specification provides support for any number of such pass-through protocols through these
588 mechanisms:

589 | **Full Encapsulation in the Message Payload** - As illustrated in [Figure 9-1](#)[Figure 9-1](#), other protocols are
590 inserted in the message payload without any modification. As described below, the organizations that
591 own and manage each protocol will define how their messaging is placed into the payload field.

Message Type	Payload Length	Payload = Pass-Through Message	Checksum
2 Bytes	2 Bytes	Variable	2 Bytes

592 **Figure 9-1 Pass-Through Message**

593

594 | **Message Type Field** – As described in [Table 3-2](#)[Table 3-2](#), each pass-through protocol is assigned a
595 “Message Type” code. This code is placed in the “Message Type” field indicated in [Figure 9-1](#)[Figure 9-1](#)
596 whenever pass-through of that protocol is occurring. This field allows end devices that might support
597 multiple protocols to recognize which is being used and to parse accordingly.

598 | **Message Type Support Query** – As indicated in [Table 5-1](#)[Table 5-1](#), a link layer query must be used to
599 determine if the other device (UCM or SGD) supports the pass-through of a particular protocol before a
600 pass-through is attempted. In this way, the support of the protocol to be passed through is known.

601 | **Maximum Message Length Negotiation** - Devices must assure that the maximum message length
602 associated with the protocol to be passed-through is supportable by the device on the other side of the
603 interface. This is to be achieved by using the Link-Layer maximum message length query described in
604 [Table 5-1](#)[Table 5-1](#).

605 | **Pass-Through Handling Instructions by the SDO** – For each protocol to be passed through in this way,
606 the standards organization that owns and manages the protocol shall produce an application note
607 describing how that protocol is to be mapped into the payload field. Such an application note will
608 define, for example, the byte or field to begin with and the byte or field to end with when passing
609 through the protocol.

610 9.1 Example Pass-Through Handling Instructions

611 9.1.1 USNAP 1.0 Protocol Pass-Through

612 This section shows how the USNAP1.0 protocol is supported by the interface. The messages will be
613 formatted as follows, with the message type being a 0x09, 0x01, and the payload being defined in the
614 USNAP1.0 specification.

Message Type = 0x09, 0x01	Payload Length	USNAP1.0 Message	Checksum
------------------------------	-------------------	------------------	----------

2 Bytes	2 Bytes	Variable	2 Bytes
----------------	----------------	-----------------	----------------

615 **Figure 9-2 USNAP1.0 over Serial**

616 The USNAP1.0 Message in the payload shall begin with the first byte of the USNAP message, called
 617 “CommandByte1”, and shall end with the last byte before the “Checksum” as identified in the USNAP1.0
 618 specification.

619 **9.1.2 SEP1.0 Pass-Through**

620 This section shows how the SEP1.0 protocol is supported by the interface. The messages would look as
 621 follows, with the message type being a 0x09, 0x05, and the payload being defined entirely by the Zigbee
 622 SEP organization.

Message Type = 0x09, 0x05	Payload Length	SEP1.0 Message	Checksum
2 Bytes	2 Bytes	Variable	2 Bytes

623 **Figure 9-3 SEP1.0 over Serial**

624 <Zigbee.org to define this section detailing how the SEP1.0 messages are to be handled>

625 **9.1.3 ClimateTalk Pass-Through**

626 This section shows how the ClimateTalk protocol is supported by the interface. The messages would
 627 look as follows, with the message type being a 0x09, 0x02, and the payload being defined entirely by the
 628 ClimateTalk organization.

Message Type = 0x09,0x02	Payload Length	ClimateTalk Message	Checksum
2 Bytes	2 Bytes	Variable	2 Bytes

629 **Figure 9-4 ClimateTalk Over Serial**


630 <ClimateTalk.org to define this section detailing how the SEP1.0 messages are to be handled>

631 **9.1.4 General Internet Protocol Pass-Through**

632 This section shows how the interface is used to support pass-through of applications over IP. This might
 633 be of interest for many purposes, including communication systems and SGDs that are capable of web
 634 access.

635 [This IP pass-through mechanism supports both IPV4 and IPV6, with the self-describing Version field of
the IP packet distinguishing between the two.](#)

637 Using the previously defined data-link commands, either the SGD or the UCM may probe the other to
 638 determine what Message types it supports. Whenever a UCM and SGD that both support pass-through
 639 of IP are connected together, the two can recognize this fact and pass-through communication can
 640 commence. When passing an IP packet over the serial interface, the UCM or SGD shall add a leading
 641 Message Type Field (0x09,0x04) and two-byte Length field; and a trailing checksum as illustrated in
 642 [Figure 9-5](#) ([IPv6 example shown, IPv4 handled in similar fashion](#)).



643

644 **Figure 9-5 Internet Protocol Pass-Through (IPV6 Example)**

645 [Use of any IP pass-through requires that the UCM and SGD support payload lengths of 2048 bytes or](#)
 646 [greater. This length must be negotiated after power up or reset using the link layer “Maximum Payload](#)
 647 [Length” negotiation described in Section 5 . IP pass-through packets may NOT be fragmented by the](#)
 648 [UCM.](#)

649

650

651

652

653

<u>Response:</u> <u>Maximum payload length</u>	<u>Message Format Per Basic DR Application</u> <u>(8 bytes total, see Table 6-1)</u> <u>Opcode1 = 0x19</u> <u>Opcode2 = Max Payload Length Indicator</u>	<u>Response to an Opcode 0x16 query.</u> <u>Max Payload Length Indicator:</u> <u>0x00 = 2 (default)</u> <u>0x01 = 4</u> <u>0x02 = 8</u> <u>0x03 = 16</u> <u>0x04 = 32</u> <u>0x05 = 64</u> <u>0x06 = 128</u> <u>0x07 = 256</u> <u>0x08 = 512</u> <u>0x09 = 1024</u> <u>0x0A = 2048</u> <u>0x0B = 4096</u> <u>0x0C = 8192</u> <u>0x0D to 0xFF reserved</u>	
---	---	--	--

654

655 10 Example Communication Exchanges

656 *Simple Serial, Request Operating State*

- 657 Comm Module to End Device → 08 01 00 02 12 00 D8 5F Opcode 0x12, what is your state?
 658 End Device to Comm Module ← 06 Link Layer Acknowledge of prev. msg.
 659 End Device to Comm Module ← 08 01 00 02 13 02 D1 63 Opcode 0x13, End device is curtailed
 660 Comm Module to End Device → 06 Link Layer Acknowledge of prev. msg.

661 *Simple Serial, Unsupported Message Followed by Shed Message*

- 662 Comm Module to End Device → 08 01 00 02 07 40 79 89 Opcode 0x07, Relative Price
 663 End Device to Comm Module ← 06 Link Layer Acknowledge of prev. msg.
 664 End Device to Comm Module ← 08 01 00 02 04 01 01 44 Opcode 0x04, App NAK, Bad Opcode
 665 Comm Module to End Device → 06 Link Layer Acknowledge of prev. msg.
 666 Comm Module to End Device → 08 01 00 02 01 00 0C 3D Opcode 0x01, Shed
 667 End Device to Comm Module ← 06 Link Layer Acknowledge of prev. msg.
 668 End Device to Comm Module ← 08 01 00 02 03 01 04 42 Opcode 0x03, App ACK of Opcode 0x01
 669 Comm Module to End Device → 06 Link Layer Acknowledge of prev. msg.

670

671 ***Query, Then Use, of Smart Energy Profile 2.0 over IP***

672 Comm Module to End Device → 09 04 00 00 CS CS Link Query, Do you support SEP2/IP

673 End Device to Comm Module ← 06 Link Layer Acknowledge of prev. msg.

674 Comm Module to End Device → 09 04 01 3D <SEP msg> CS CS SEP2/IP msg, length only an example

675 End Device to Comm Module ← 06 Link Layer Acknowledge of prev. msg.

676 * Note that the Basic DR application ACK (Opcode 0x03) is only used in response to Basic DR commands
677 (message type 0x08, 0x01). Once SEP2/IP is used (message type 0x09, 0x04), then the application layer
678 acknowledge, if any, is up to the SEP2 specification.

679 ** Note that the UCM does not have to initiate communications. For example, an SGD can initiate an IP-
680 based exchange of information.

681 **11 General Security Principles**

682 The serial interface between a UCM and an SGD supports end-to-end security at the application layer
683 and/or at the IP / network layer. It is not encrypted at the link layer. For certain application protocols,
684 such as the Basic DR, it is not encrypted. In this case, the socket interface is treated as a protected local
685 interface like any other wired connection between circuit boards inside a product. If the communication
686 on the communication network (PLC, wireless, etc) is encrypted, as it may be in a secured Wi-Fi or
687 Zigbee HAN for example, the decryption may occur in the communication module or be passed through
688 to the SGD, if supported.


689 In the case of more advanced protocols, like internet pass-through, encryption may exist within the IP
690 packet embedded in the serial message. For example, if the communication network is Wi-Fi, then a Wi-
691 Fi communication module may receive an IP packet wirelessly, strip-off any 802.11 phy/mac part, insert
692 the IP packet as the “Payload” in the message structure shown in [Table 3-1](#), and send it on
693 through to the SGD. In this case, the communication module would be serving as a phy/mac translator
694 and would know nothing of the packet’s content, which may or may not be encrypted. The comm
695 module would only know whether or not the SGD is accepting or NAK’ing the messages.

696 **12 Load Management Event Randomization**

697 It is noted that if large numbers of end devices turn on or off simultaneously there may be an
698 undesirable sudden change in load on the power system. This unnatural synchronization could result in
699 voltage problems on distribution systems. This type of situation could occur in a broadcast-type
700 communication system (pager, FM, PLC) where a real-time request to shed load is sent to a large
701 number of devices at once. Another scenario that would cause similar alignment is that of a scheduled

702 event where a large number of devices are all responding to a common schedule, such as a high price
703 period that begins or ends at a specific time.

704 Unless explicitly identified in the application layer command (e.g. the Intermediate cycling command),
705 this interface specification does not require SGDs to perform event randomization. In fact, such
706 behavior could prevent the device from being used for certain time-sensitive services, such as
707 compensation for intermittent renewable generation. Rather, the utility, communication system, or
708 UCMs, shall perform randomization, if desired. The advantage of this approach is that it allows a single
709 SGD to be sold nationwide without assuming to know what timings are needed by the local utility.
710 [Figure 12-1](#)[Figure 12-1](#) illustrates this concept.



711

712

Figure 12-1 Example of Randomization of Events by Communication Modules

713

714 **13 Appendix A – Low Voltage DC Form Factor**

715 **13.1 Overview**

716 **13.1.1 Limitations**

- 717 • The transport speed is limited by SGD and UCM processor bandwidth. The data link defaults to a
718 slow data rate (19.2k) and small payload(2 bytes). Data link layer commands allow negotiating the
719 speeds and payloads for more capable devices. Process for reverting to default settings is also
720 documented at the application layer.
- 721 • This specification does not include device reliability requirements. There are also no specifications for
722 handling, dropping, ESD resistance, etc. It is expected that manufacturers will make appropriate
723 design decisions, and that the market will reward those who make good decisions.

724 **13.2 Physical Layer**


725 **13.2.1 Power for UCM**

726 Power for UCM is provided by SGD. Power is supplied at 3.3 +/- 0.3V DC. The power consumption limits
727 are described in section 5.1.2 .

728 **13.2.2 Mechanical Interface**

729 13.2.2.1 DC Form Factor Board Layout

730 The DC UCM device must conform to one of the physical layouts identified in [Figure 13-2 and Figure](#)
731 [13-3](#). The Standard DC UCM layout is designed to fit inside the SGD while the Extended Size DC UCM
732 may protrude outside the SGD. It includes an extended segment where larger components and external
733 connectors may be included. The extended size DC UCM allows extension of 51mm dimension. All
734 dimensions within the envelope of the standard size radio must be met.



735

736

Figure 13-1 DC Form Factor PCB Dimensions


737 13.2.2.2 Module Configuration

738 The DC form factor UCM module is defined for the standard layout. Extended size UCMs will have
 739 extended housings which are required to have all the features and meet all the dimensions of the
 740 standard module with the exception of the 51mm dimension.


741 A special case of extended length is defined for antennas and wired media. The side of the module
 742 opposite of the connector is reserved for extending an antenna or accessing the wired media.

743 For example, PLC media that need access to the power line or wired media could provide a cord
 744 terminated with a Nema 1-15 plug. Another example could be a wired ethernet module with an RJ45
 745 receptacle. Specific implementations are left to the discretion of the communication provider.

746



747



748

749

Figure 13-2 DC Form Factor Housing Dimensions – Top View




USANP_Radio_Spec.
pdf

750

* Hatched Area Dimensions for connectors, antennas, or large components

751




752

753

[Figure 13-3 DC Form Factor Housing Dimensions – Side View](#)

754 * Hatched Area Dimensions for connectors, antennas, or large components



755

756

Figure 13-4 DC Form Factor Housing Dimensions – End View

757

758




Figure 13-5 DC Form Factor Housing Visualization

761 13.2.2.3 Weight

762 The maximum weight for a DC form factor cartridge is 40 grams.

763

764 13.2.2.4 Housing Materials

765 UCM housing materials must be appropriate for the technology contained within and the environment
766 where the device is expected to operate. UCMs are expected to operate in an indoor environment
767 protected from weather. If SGD operates in a severe environment (i.e. temperatures, UV, Chemicals,
768 etc.) it should provide necessary protection.

769 HousingIf SGDs are UL Recognized Class 2 supply (IEC SELV), then the housing flammability rating of
770 UCMs can be UL94-HB. Otherwise UCM housings must be UL94-V0.

771 should be a minimum of UL94 HB, unless the UCM hasThese are minimum requirements, and UCMs
772 with internal characteristics that require a higher degree of protection may require higher flammability
773 standards.

774 13.2.2.5 Connector Type

775 The interface connector on the SGD is a 10-pin 2mm pin header.

776 —————Numerous parts are available including custom heights and lengths. Sample straight and right
777 angle parts: Harwin [M22-2351005](#)[M22-2531005](#) Harwin M22-2511005 Samtec TMM-
778 110-03-S-S-RA

779

780 Gold coatings are required on UCM to SGD interface for reliability.
781 UCMs will provide a mating 2mm receptacle, Harwin Part Number M22-7131042 or equivalent.
782 Alternate mating part SAMTEC SQT-110-01-L-S-RA

783

784 13.2.2.6 Pin Assignments

785 The pin assignments of the connector are defined as follows.


Pin	Signal “A” Device
1	SELECT*, must be held high when not communicating with UCM
2	ATTENTION*
3	SCLK
4	MOSI
5	MISO
6	RESET*
7	+3.3V Power
8	Signal Ground
9	Reserved
10	Reserved

786 13.2.2.7 Electrical Interface Levels

787 All signals are 3.3V Logic Levels. Logic ‘0’ is defined as less than 0.8V, and Logic ‘1’ as greater than 2.2V.

788 13.2.2.8 Signal Timing

789 Representative signal timing is shown for SPI byte transfers:



791 **Figure 13-63 SPI Mode 0 Bit Timing**

- 792 This specification supports SPI Mode 0 only.
- 793 Data changes on the falling edge and should be read on the rising edge.
- 794 Data (MISO) from the UCM is high impedance when SELECT is high.

795 13.2.2.9 Interface Circuits

Circuit(s)	Direction	active state	Purpose
Signal Ground	n/a	n/a	Establishes a common ground potential
+3.3V Power	From SGD	n/a	Provides +3.3V power for radio use
MOSI	from SGD	High	Carries SGD SPI data to UCM
MISO	From UCM	High	Returns UCM SPI data to SGD, High Z when SELECT is high.
SCLK	From SGD	Rising Edge	SPI clock signal from SGD
SELECT*	From SGD	Low	Low during each byte of SPI data transfer. Normally high. SGD can assert (low) to request data transfer with radio.
ATTENTION*	From UCM	Low	Signal from UCM Requesting an SPI data transfer
RESET*	From SGD	Low	Signal from SGD negated after power-on. Open collector/drain output.
Reserved (Factory Test)	N/A	N/A	Two signals for SGD test use at factory only. UCM must not connect to these pins.

796

797 13.2.2.10 Data Transfer Protocol

798

799 ATTENTION*

- 800 This signal is asserted (driven low) by the UCM whenever it is ready to initiate a data byte transfer across
801 the SPI. In general it is expected that ATTENTION* will be asserted during the entire time of a message
802 from the UCM and the SGD response (if any).

803 SELECT*

- 804 This control signal is driven low before each message is transferred via SPI, and driven high after the
805 message transfer is complete. The SGD normally parks this line high. When SELECT is high, the UCM
806 MISO data line must be in a high impedance state. Separate SELECT signals are provided to each UCM.

- 807 In a secondary usage, the SGD may initiate data transfer to a UCM (in the course of a data transfer from

808 one UCM to another for instance). In this type of transfer, the SGD can drive the SELECT signal low to
809 request ATTENTION* from the UCM. The UCM can acknowledge this request by asserting (driving low)
810 the ATTENTION* signal (initiating a data transfer).

811 In a tertiary usage, the SGD may use this signal to determine presence of the UCM. The SGD drives the
812 SELECT line low. If the SGD detects the UCM pulling the ATTENTION* line low the SGD confirms the
813 presence of the UCM, and then releases the SELECT signal to the high State.

814 RESET*

815 On power-on, the SGD will assert Reset* (drive it low) for a minimum of 100mS. This signal is open-
816 collector (open-drain); it is the responsibility of the UCM to provide any pull-up, if required. Separate
817 Reset* signals are provided to each UCM.

818 13.2.2.11 Clock and Data Rate

819 Data rate is controlled by the SPI SCLK. SCLK is generated by the SGD. Standard data rates are defined
820 in section 5.1.3 .

821 13.2.2.12 Multiple Slots

822 SGD's may, but are not required to provide multiple slots.

823 Select, Attn, Reset must be provided to each slot.

824 Power, Common, Clock, MOSI, MISO are common among all slots.

825 SGD device manufacturers may allocate bandwidth between the slots as necessary.

826

827 **13.3 Data Link**

828 The SPI is physically capable of transferring data in both directions simultaneously. However, data is
829 only sent in a single direction at a time. The first side to assert the signal line is the sender. The receiver
830 will always send a 0xFF character during data transfer.

831 If a node is detecting data on the receive line at the same time it is transmitting it has 2 choices.

- 832 1) Ignore it, at end of transmission when the node does not reply with a <ACK> or <NAK> the
833 sending device will try again.
- 834 2) Read the incoming message and buffer it for essentially full duplex communication. Attempt to
835 <ACK> or <NAK> for the message when message is complete and line becomes open. This
836 option requires a more complex state machine that also keeps track of the state of both transfer
837 directions, and is not a requirement.

838 ***13.3.1 Messages***

839 **13.3.1.1 Frame Structure**

840 The message frame structure is defined in section 3 . Message transfer is framed by the SELECT* and
841 ATTENTION* lines.

842 **13.3.1.2 Message Synchronization (Frame Delimiting)**

843 Synchronization (detection of the start of a message) is achieved by the use of the SELECT* and
844 ATTENTION* lines. Message transfer occurs when the UCM has asserted ATTENTION*, the SGD has
845 asserted SELECT* and the SGD begins to clock data. The order of SELECT* and ATTENTION* depends on
846 which device is initiating the data transfer.

847 **13.3.1.3 Message Filling (Inter-message byte filling)**

848 When a device is not sending a message, but SPI transactions are occurring, devices will fill using the
849 special fill byte 0xFF.

850 **13.3.1.4 Command/Response Encoding**

851 Message IDs and responses are encoded as binary bytes. The application layer will define commands to
852 support the application requirements.

853 **13.3.1.5 Checksum Calculation**

854 The checksum calculation is defined in Appendix “D”.

855 **13.3.1.6 Master/Slave**

856 **13.3.1.7 The SGD is the master of the SPI bus. It generates the SPI clock and drives MOSI. Flow Control**
857 The UCM controls data flow by using the ATTENTION* line. Flow control is achieved by the SGD through
858 its' control over the SPI data transfer.

859 When there are multiple messages queued to send, the SGD or UCM will wait until the prior message
860 has been acknowledged, Not Acknowledged, or the Inter-Message timeout has expired before initiating
861 the next message.

862 When a UCM or SGD receives a message to send from it's application while it is in the process of
863 receiving a message, it will Acknowledge or Not acknowledge the message it is receiving. Allow
864 SELECT*/ATTENTION* to be de-asserted, and then initiate transfer of new message.

865 Note: To support separation of layers this allows multi-threading. This does not require an application
866 to support multi-threading, but creates a mechanism to allow it if desired.

867

868 13.3.1.8 Error Detection and Recovery

869 13.3.1.9 SGD Error Detection and Recovery

870 The following errors shall be detected at the SGD device data link level:

- 871 • Check byte error;
- 872 • Invalid Length - Upon receipt of the initial 4 bytes of header, if the length is out of range() the SGD
873 will de-assert SELECT*;
- 874 • Inter-message time-out. – When waiting for an ACK, if no response is received in 100 milliseconds,
875 the SGD times out and returns to IDLE state. SGD may then attempt to transfer message again. This
876 does not generate a <NAK>; and
- 877 • Message Initiation failure. – When SELECT* has been asserted, if no response is received in 100
878 milliseconds, the SGD times out, de-asserts SELECT* and returns to IDLE state. SGD may then
879 attempt to transfer message again. This does not generate a <NAK>.

880 Additional error checking shall be performed at the SGD device application level, including data out of
881 range.

882 13.3.1.10 UCM Error Detection and Recovery

883 The following receive errors may be detected at the UCM data link level:


- 884 • Invalid byte;
- 885 • Check byte error;
- 886 • Intra-message time-out error, When a message has been initiated by either device and is ready to send
887 as indicated by both Select and Attention being asserted, and an insufficient number of bytes has been
888 clocked by the SGD (including no bytes). If this does not occur in 500 milliseconds, the UCM times
889 out, de-asserts ATTENTION* and returns to IDLE state. This does not generate a <NAK>
- 890 • Invalid Length - Upon receipt of the initial four bytes of header, if the length is out of range the UCM
891 will de-assert ATTENTION*;
- 892 • Extra Bytes - If the SGD continues to clock beyond where the check-byte was expected, the UCM de-
893 asserts ATTENTION*;
- 894 • Inter-message time-out. – When waiting for an ACK or when ATTENTION* has been asserted, if no
895 response is received in 100 milliseconds, the UCM times out and returns to IDLE state. UCM may
896 then attempt to transfer message again. This does not generate a <NAK>; and
- 897 • Message Initiation Failure. – When ATTENTION* has been asserted, if no response is received in
898 100 milliseconds, the UCM times out, de-asserts ATTENTION* and returns to IDLE state. UCM may
899 then attempt to transfer message again. This does not generate a <NAK>.

900

901 Additional error checking may be performed at the UCM application level

902 **13.3.2 Operation**

903 13.3.2.1 Transaction Sequence



904

Figure 13-74 SPI Transaction Sequence

- 906 1. The SGD begins the transaction by setting SELECT* low. The UCM then sets ATTENTION* low.
907 The SGD then starts clocking out data.
- 908 2. After clocking out the packet, the SGD sets SELECT* high. The UCM then sets ATTENTION* high.
- 909 3. When the UCM has a response ready, it sets ATTENTION* low. The SGD sets SELECT* low and
910 then starts clocking data.
- 911 4. When the packet has completed, the UCM sets ATTENTION* high. The SGD also sets SELECT*
912 high.

913 For communications initiated by the UCM, the sequence is reversed.

914 13.3.2.2 Collision Detection

915 ~~The SGD, as the SPI master may experience situations where SELECT* and ATTENTION* are both asserted at about the same time. Link layer retries with randomized delays shall be used to recover from such events.~~

918






Figure 13-5 SPI Collision Detection13.3.2.2 SPI Data Transfer State Machine

922 This state machine diagram describes the behavior of both the UCM and A-SGD when transferring data
923 over the U-SNAP interface. Data transfer can be initiated on either side by asserting the appropriate
924 signaling line, ATTENTION for the UCM and SELECT for the SGD.

925

926 13.3.2.3 SGD Transmitter Operation

927 The SGD device transmitter must perform the calculation of the checksum to be transmitted with each
928 message, encode both the message and the checksum, and queue messages for transmission.

929 If the SGD has a message to send it will assert SELECT.

930 Upon UCM asserting ATTENTION, the SGD will clock 1 bytes.

931 If message was ACK, SGD will de-assert SELECT.

932 If message was NAK, SGD will clock one additional byte and de-assert SELECT.

933 Otherwise

934 SGD will clock remainder of the message and de-assert SELECT.

935 SGD will then await an ATTENTION from UCM, to receive and ACK or NAK.

936 If ACK received,

937 SGD will de-assert SELECT, and return to idle.

938 If NAK received or a new message is received from UCM,

939 SGD transmitted notify application of transmit failure.

940 SGD may attempt to transfer again.

941 It is recommended that developers put an algorithm in place to handle NAKs/Timeouts. A retry
942 counter, or an increasing delay between attempts, or evaluating the message at the application level to
943 see if it is still valid are options.

944

945 13.3.2.4 SGD Device Receiver Operation

946 The SGD Device receiver must perform the following functions:

947 • Detect the request to transfer from UCM,

948 • Detect message length,

949 • Decode the incoming message,
950 • Generate ACK or NAK messages as appropriate, and
951 • Route messages to the appropriate application task.
952 The SGD Device receiver initially enters an IDLE state.

953 If the ATTENTION line is asserted by the UCM, the SGD Device receiver asserts the SELECT line and
954 enters the data transfer state and clocks in one data bytes.

955 If ACK received,

956 SGD will wait for UCM to de-assert ATTENTION, then de-assert SELECT, and return to idle.

957 If NAK received,

958 SGD will clock 1 additional byte, wait for UCM to de-assert ATTENTION, then de-assert SELECT, and
959 return to idle.

960 Otherwise,

961 The SGD will clock the third and fourth bytes is the (message count bytes). [If this is invalid an
962 error is generated and receipt aborted]

963 The SGD then clocks in the balance of the message (data bytes plus the check sum byte,). The
964 receiver then awaits the de-assertion of ATTENTION. Upon de-assertion of ATTENTION the Receiver de-
965 asserts SELECT.

966 The receiver then computes the checksum, and then queues an Acknowledgement or a Not
967 Acknowledgement for transmission. The receiver then forwards the message to the application (if
968 correct) or discards (if incorrect) and returns to IDLE state.

969 13.3.2.5 UCM Operations

970 The UCM performs the same functions as the SGD, with the following changes:

971 • The actions of SELECT and Attention are reversed.
972 • The UCM has to monitor for Message Timeout.
973 • The UCM relies on the SGD to clock the bytes.

974 **14 Appendix B – AC Form Factor**

976 **14.1.1 Physical Form**

977 The connector shown in [Error! Reference source not found.](#) [Figure14-1](#) provides sufficient clearance for
978 the 120/240Vac signals. In the case of 120V appliances, AC+ is shall be the hot connection and AC- is shall
979 be the neutral connection. In the case of 208/240V three wire appliances, AC+ is shall be phase A and
980 AC- is shall be phase B. The connector includes protective sleeves to cover the energized pins, has some
981 circuits removed to increase clearance around the AC power, and is polarized so that the mating device
982 can only be plugged-in one way. The connector part that would go on the SGD is available from Molex
983 as 44516-1006, using pins (quantity eight) Molex 39-00-0039. The mating part, which would be used on
984 a communication module that plugged-in at a right angle, is Molex 43459-0051.

985 <mechanical details, second source and connector detail drawings to be inserted here>



1	Data- (RS-485)	7	Data+ (RS-485)
2	No Connection	8	Signal Ground
3	Reserved for vendor-specific use	9	No Connection
4	No Connection	10 ₁	Earth Ground
5 ₁	120VAC Line 2	11	No Connection

6	No Connection	12 ₁	120VAC Line 1
---	---------------	-----------------	---------------

988 Note: AC power pins utilize 18AWG wires. All others utilize 22AWG


989 **Figure14-1 AC Connector Form Factor (Appliance Side Shown) and Pin-Out**

990 **14.1.2 AC Power**

991 UCMs must be designed to operate normally over a voltage range from 10% under the nominal service
992 voltage to 20% over the nominal voltage. This equates to 96 to 288Vac for 120 to 240V systems. UCMs
993 must be auto-ranging. Current consumption on the AC lines may not exceed the limits indicated in [Table](#)
994 [5-3](#)[Table 5-3](#). SGDs providing this connection may optionally choose to limit the current to these levels.

995 **14.1.3 Serial Electrical Interface**


996 This is an EIA RS-485 2-wire connection on pins 7 (Data+) and 1 (Data-), operating at a nominal voltage
997 of 5V as illustrated in [Figure 14-2](#)[Figure 14-2](#).



998
999

Figure 14-2 Typical RS-485 Polarity and Byte Transfer

1000 The RS-485 interface is anticipated to employ a driver IC. The use of such a driver provides protection
 1001 against ESD and other transients and potential noise problems. RS-485 is multi-drop capable, allowing
 1002 the serial port going into the appliance to connect to multiple sub-systems inside the appliance if
 1003 desired. The default state for this bus is a logic “1”, with the bias provided by the SGD via a 1K ohm pull-
 1004 up resistor on the Data+ line to +5V and a 1K pull-down resistor to GND on Data- provided by the SGD as
 1005 illustrated in [Figure 14-3](#)[Figure 14-3](#).



1006
1007

Figure 14-3 RS-485 Connections

1008 The default baud rate on the interface is 19.2KBaud with one start bit (0), eight data bits, no parity, and
 1009 two stop bits (1's). Transmitters must send two stop bits, receivers must tolerate one or more.

1010 **14.1.4 Obtaining Message Sync**

1011 Because the serial message structure does not employ a special start character, bus idle (logic “1” state)
 1012 for 20[mS] or more shall indicate the start of a new message. During a packet transfer, transmitters

1013 must assure that the inter-character delay is less than this time. Receivers are only required to report
1014 | time-outs at the message level, per the T_{ML} specification in [Table 3-3](#)[Table 3-3](#). Receivers are not
1015 required to measure inter-byte delay, other than when searching for the start of a new message. There
1016 is no LINK NAK error code associated with inter-byte delay.

1017

1018

1019 **15 Appendix C – Fletcher Checksum**

1020

1021 The checksum method for this protocol is a “Fletcher’s Checksum”. The two bytes are coded
1022 and decoded as follows:

1023 **15.1 Calculating the Checksum**

1024

1025 Initialize check1 to 0xAA and check2 to 0x00

1026 Use a temporary variable to read in bytes, call it “checktemp”

1027 Loop through the message (first message type byte to end of payload) to find the check numbers.
1028 This loop excludes the checksum bytes as they are not yet created.

1029 check1 = (check1 + checktemp) Mod 255

1030 check2 = (check2 + check1) Mod 255

1031 Find the bytes to append in the following manner:

1032 mscheckbyte = 255 - ((check1 + check2) Mod 255) (the MSB of the completed checksum)

1033 lscheckbyte = 255 - ((check1 + mscheckbyte) Mod 255) (the LSB of the completed checksum)

1034 **15.2 Decoding the Checksum**

1035

1036 Initialize check1 to 0xAA and check2 to 0x00

1037 Use a temporary variable to read in bytes including the checksum, call it “checktemp”

1038 Loop through the message to find the check numbers.

1039 check1 = (check1 + checktemp) Mod 255

1040 check2 = (check2 + check1) Mod 255

1041 Once the entire message including the two checksum bytes have been analyzed, check1 and
1042 check2 should equal 0x00.

1043 **15.3 Example VB Code**

1044 Creating Checksum:

```

checkbyte1 = 170 '0xAA
checkbyte2 = 0    '0x00

For I = 1 To Len(senddata) Step 1
    checktemp = Asc(Mid(senddata, I, 2))
    checkbyte1 = (checkbyte1 + checktemp) Mod 255
    checkbyte2 = (checkbyte2 + checkbyte1) Mod 255
    checktemp = 0
Next I

mscheckbyte = 255 - ((checkbyte1 + checkbyte2) Mod 255)
lscheckbyte = 255 - ((checkbyte1 + mscheckbyte) Mod 255)

```

1045

1046 Decoding Checksum

```

Public Function GoodChecksum(incoming As String) As Boolean
checkbyte1 = 170
checkbyte2 = 0

For I = 1 To Len(incoming) Step 1
    checktemp = Asc(Mid(incoming, I, 2))
    checkbyte1 = (checkbyte1 + checktemp) Mod 255
    checkbyte2 = (checkbyte2 + checkbyte1) Mod 255
    checktemp = 0
Next I

If checkbyte1 = 0 And checkbyte2 = 0 Then
GoodChecksum = True
Else
GoodChecksum = False
End If

```

1047

1048 16 Appendix D – Guideline for Computing Average Price

1049

1050 This appendix explains the calculation of the Average Price (AP) from which the relative price of section
1051 4.0 is computed.

1052 Electric rates structures, today, are very complex and vary in every jurisdiction. Common elements of
1053 rate design consist of components like fixed charges per month (including customer charge, flat tax or
1054 levy fees), a unchanging prices per kWh (often to recovery fixed costs charge on a per kWh basis), peak
1055 kW demand charges, a percent tax (or tax equivalent) adder on certain charges, and worst of all, block
1056 rates that cause a higher (or lower) rate kWh when usage during a billing period moves above a certain
1057 quantity of use. (Some rates even have multiple blocks).

1058 Note: Average price by state and sector are here:
1059 http://www.eia.gov/cneaf/electricity/epm/table5_6_b.html. However, these average prices are
1060 inclusive of all fixed and flat rate charges. AP based on more than TVC is desirable from a customer
1061 perspective but there is no way to reconcile block rate designs with average price since two customers
1062 can have significantly different average prices from a monthly bill perspective. Also observe
1063 that averaged at the state level, the total price per kWh varies between 8 and 28 cents per kWh; this
1064 should emphasize the problem of trying to communicate actual price and have anything but a complex
1065 application make sense of it. Everyone can understand price relative to the expected monthly bill.

1066 The relative price command only applies to the bill components that relate to price changes as a
1067 function of time during a day or hour. ("Time Varying Charges, TVC") Most commonly TVC charges apply
1068 to the cost of energy generation, but in some rate designs charges for the fixed cost of distribution may
1069 also be time varying. TVC exclude kW, demand charges if any. The purpose of command 0x07 is to
1070 convey the bundled price of all TVC which affect the retail customer's bill. Thus the service provider
1071 responsible for conveying price signals via the UCM combines all TVC even if the service provider only
1072 provides energy or distribution services. The following instructions assume that block rate price
1073 increase or decreases have no relationship to time only the usage in a billing cycle. (This is the most
1074 common outcome. It has the effect of say the flat price per kWh is \$X/kWh for the first Q use and then
1075 \$Y/kWh for the next block of usage. Depending on the time varying price structure the bill calculation
1076 add or subtracts dollars depending on the block rate structure, but not dependent on when in a day
1077 usage was consumed.)

1078 The following explanation gives examples with prices quoted in mills per kWh. (This is numerically equal
1079 to \$ per MWh the unit of price in wholesale markets. Retail customers are commonly quoted prices in
1080 cents per kWh; cents per kWh equals mills per kWh divided by ten.)

1081 A utility or service provider using this command should be willing (or regulated) to provide to their
1082 customer a basis for the average price ("AP") per kWh that pertains to TVC; relative prices equals
1083 current price divided by AP. The intent of the AP is to convey the price per kWh, pertaining to TVC, that
1084 produces an average bill amount. Example let's say a bill consists of 3 components, a fixed charge per
1085 month of \$11 (including flat taxes), a flat rate of 41.2 mills (40 mills per kWh plus a 3% tax) and an AP of
1086 TVC equal to 82.4 mills (80 mills plus 3% tax). Lets say the customer uses 800 kWh per month. The the
1087 intent of AP is to convey that the customer on the rate would receive a bill of \$65.92 for TVC, **IF** the
1088 customer's usage pattern matches the statistical average load shape with respect to time. ($\$65.92 = \$82.$
1089 $4/\text{MWh}$ time 0.8 MWh). Note the customer's total bill would be $\$109.88 = \$11 + \$32.96 + \65.92 Thus if
1090 the customer use more energy in higher-priced hours than the average customer they would expect a
1091 higher bill being on this time varying rate design.

1092 *Explanation for non-regulated utilities.*

1093 The above task is a straight-forward exercise today for any regulated utility (public or private);
1094 ratemaking 101 if you will. However, in a smart grid world with multiple rates and multiple providers,

1095 the best we are likely to do is set AP at a value close to the average TVC, more importantly at a level the
1096 make the relative prices (dynamic prices divided by the AP) as indicative of the correct relative price to
1097 the consumer.

1098 For regulated utilities most customer are a flat rate price per kWh that represents the sum of fixed and
1099 TVC (to the utility). In the creation of a time varying rate the first step is to be explicit about how much
1100 of the flat rate will remain at flat price per kWh and how much will be collected through time a time
1101 varying rate. Through load research, for customers of a given class, say residential, a known load shape
1102 for the average customer is known. Load shape is the percent of total energy use per hour for each hour
1103 of the year. This shape can be based on all customers or just customers on a flat rate design. Expected
1104 revenue from a given time varying rate is calculated using this model. Consider a two price time-of-day
1105 rate. Low rate period is 10p to 6a every day and high price 6a to 10p every day. By looking at the load
1106 shape you would determine that 25% of the energy is use in the low rate period. If flat rate price is 120
1107 mills and 80 mills are to be collected in TVC, then to achieve and AP of 80 mills in TVC and the low price
1108 is 50 mills, then the high price is 91.67 mills. Relative price when the low price is in effect is 0.563.
1109 Relative price when high price is in effect is 1.146. Note when a 3% tax is added the relative prices
1110 remain unchanged. This example is the simplest type of design. Introducing a third price period allows
1111 much more flexibility in designing the behavior desired from the customer and also the rates
1112 marketability. Critical peak pricing and real time pricing introduce a new variable in that the specific
1113 period when a price will be available is not know ahead of time. Rate design is based on expected
1114 pricing outcomes.

1115 AP for TVC was assumed at 80 mills. This type of rate designed is called "revenue neutral" because both
1116 the flat rate and time-varying rate collect are designed to collect 120 mills per kWh for the average
1117 customer. It is expected that the customer with time varying rates will shift some loads to the low price
1118 period thus creating a net billing savings to the customer. However there are economists would argue
1119 time varying-rates should be lower than revenue neutral to reflect that customers that don't wish to
1120 deal with peak supply cost problems should pay a premium for the risk burden they put on the energy
1121 supplier relative to someone who faces time-varying pricing. Critical peak pricing and real time pricing
1122 introduce a new variable in that the specific period when a price will be available is not know ahead of
1123 time. Rate design is based on expected pricing outcomes.

1124 The complexity of rate designs in the last paragraph raise a number of issues about how to determine
1125 AP. For example is AP based on all customers 1) in a given region, 2) of a given provider, 3) on a specific
1126 rate, before or after shifting is accounted for. If the rate is based on real time rates what index or
1127 forecast is used to determine average rates.

1128

1129 *Summary*

1130 With regard to this standard and this command there are no absolute rules that can be workable against
1131 all the future outcomes of regulation and market forces. Imagine coming with a relative price of for a
1132 coach round trip airline seat between Washington DC and Tampa Florida in 1977 before deregulation in
1133 October 1978. Average price would have been fairly easy to determine. Relative prices for the
1134 Wednesday before thanksgiving would have been relatively easy to determine also. Today we might
1135 guess the price at \$250, and feel that \$200 would be a great price and \$500 a very high price. We would
1136 feel fortunate if someone even gave us a relative constant metric of average price.

1137 This analogy is only mentioned to show how pricing models to improve asset utilization can change
1138 dramatically over time. However unlike airplane flights which are expensive, relatively infrequent
1139 transactions, electricity use is like a leaky faucet-- continuous use with small cost incurred during most
1140 periods. This command only works, a machine to machine interface, if the consumer can use the signal
1141 to manage the size of their electric bill. A service provider that games the signal will eventually be found
1142 out, if a large risk of damage to market credibility.

1143 Thus the rules for determining AP can be summarized as follows

1144 -AP shall be based on TVC only

1145 -AP price is set to indicate the price that will produce the average bill for TVC.

1146 -In the near term, AP should be calculated in a manner similar to rate designs for regulated entities.

1147 -In the future, AP should be set (ideally held constant for at least a quarter if not a year) at a level that
1148 provides intuitive messages via the relative price signals to customers.

1149